

# HTR-5850/HTR-5840

AV Receiver

## **IMPORTANT SAFETY INSTRUCTIONS**



#### CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

#### Explanation of Graphical Symbols



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

- 1 Read Instructions All the safety and operating instructions should be read before the product is operated.
- 2 Retain Instructions The safety and operating instructions should be retained for future reference.
- **3** Heed Warnings All warnings on the product and in the operating instructions should be adhered to.
- 4 Follow Instructions All operating and use instructions should be followed.
- 5 Cleaning Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- 6 Attachments Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- Water and Moisture Do not use this product near water for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
- 8 Accessories Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
- 9 A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

- 10 Ventilation Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- 11 Power Sources This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- 12 Grounding or Polarization This product may be equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
- Power-Cord Protection Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
- 14 Lightning For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- 15 Power Lines An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- 16 Overloading Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 17 Object and Liquid Entry Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 18 Servicing Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 19 Damage Requiring Service Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
  - a) When the power-supply cord or plug is damaged,
  - If liquid has been spilled, or objects have fallen into the product,
  - If the product has been exposed to rain or water,


- d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation,
- e) If the product has been dropped or damaged in any way, and
- f) When the product exhibits a distinct change in performance this indicates a need for service.
- 20 Replacement Parts When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- 21 Safety Check Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 22 Wall or Ceiling Mounting The unit should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 23 Heat The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

#### Note to CATV system installer:

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

24 Outdoor Antenna Grounding – If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

#### **EXAMPLE OF ANTENNA GROUNDING**



#### **FCC INFORMATION (for US customers)**

## 1 IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

- 2 IMPORTANT: When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.
- 3 NOTE: This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices.

This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to coaxial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Electronics Corp., U.S.A. 6660 Orangethorpe Ave, Buena Park, CA 90620

The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

## **CAUTION: READ THIS BEFORE OPERATING YOUR UNIT.**

- 1 To assure the finest performance, please read this manual carefully. Keep it in a safe place for future reference.
- 2 Install this sound system in a well ventilated, cool, dry, clean place – away from direct sunlight, heat sources, vibration, dust, moisture, and/or cold. Allow ventilation space of at least 30 cm on the top, 20 cm on the left and right, and 20 cm on the back of this unit.
- 3 Locate this unit away from other electrical appliances, motors, or transformers to avoid humming sounds.
- 4 Do not expose this unit to sudden temperature changes from cold to hot, and do not locate this unit in a environment with high humidity (i.e. a room with a humidifier) to prevent condensation inside this unit, which may cause an electrical shock, fire, damage to this unit, and/or personal injury.
- 5 Avoid installing this unit where foreign object may fall onto this unit and/or this unit may be exposed to liquid dripping or splashing. On the top of this unit, do not place:
  - Other components, as they may cause damage and/or discoloration on the surface of this unit.
  - Burning objects (i.e. candles), as they may cause fire, damage to this unit, and/or personal injury.
  - Containers with liquid in them, as they may fall and liquid may cause electrical shock to the user and/or damage to this unit.
- 6 Do not cover this unit with a newspaper, tablecloth, curtain, etc. in order not to obstruct heat radiation. If the temperature inside this unit rises, it may cause fire, damage to this unit, and/or personal injury.
- 7 Do not plug in this unit to a wall outlet until all connections are complete.
- 8 Do not operate this unit upside-down. It may overheat, possibly causing damage.
- 9 Do not use force on switches, knobs and/or cords.
- 10 When disconnecting the power cord from the wall outlet, grasp the plug; do not pull the cord.
- 11 Do not clean this unit with chemical solvents; this might damage the finish. Use a clean, dry cloth.
- 12 Only voltage specified on this unit must be used. Using this unit with a higher voltage than specified is dangerous and may cause fire, damage to this unit, and/or personal injury. YAMAHA will not be held responsible for any damage resulting from use of this unit with a voltage other than specified.
- 13 To prevent damage by lightning, disconnect the power cord from the wall outlet during an electrical storm

- 14 Do not attempt to modify or fix this unit. Contact qualified YAMAHA service personnel when any service is needed. The cabinet should never be opened for any reasons.
- 15 When not planning to use this unit for long periods of time (i.e. vacation), disconnect the AC power plug from the wall outlet.
- 16 Be sure to read the "TROUBLESHOOTING" section on common operating errors before concluding that this unit is faulty.
- 17 Before moving this unit, press STANDBY/ON to set this unit in the standby mode, and disconnect the AC power plug from the wall outlet.

#### **WARNING**

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

This unit is not disconnected from the AC power source as long as it is connected to the wall outlet, even if this unit itself is turned off. This state is called the standby mode. In this state, this unit is designed to consume a very small quantity of power.

#### FOR CANADIAN CUSTOMERS

To prevent electric shock, match wide blade of plug to wide slot and fully insert.

This Class B digital apparatus complies with Canadian ICES-003.

#### **IMPORTANT**

Please record the serial number of this unit in the space below.

MODEL:

Serial No.:

The serial number is located on the rear of the unit. Retain this Owner's Manual in a safe place for future reference.

#### We Want You Listening For A Lifetime

YAMAHA and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion – and, most importantly, without affecting your sensitive hearing.

Since hearing damage from loud sounds is often undetectable until it is too late, YAMAHA and the Electronic Industries Association's Consumer Electronics Group recommend you to avoid prolonged exposure from excessive volume levels.



## CONTENTS

INTRODUCTION		
FEATURES	2	
GETTING STARTED		
Supplied accessories		
Installing batteries in the remote control		
CONTROLS AND FUNCTIONS	4	
Front panel	4	
Remote control	6	
Using the remote control	7	
Front panel display	8	
Rear panel	10	

PREPARATION	
SPEAKER SETUP	11
Speaker placement	11
Speaker connections	12
CONNECTIONS	14
Before connecting components	14
Connecting video components	16
Connecting audio components	19
Connecting the FM and AM antennas	20
Connecting the power supply cord	21
Speaker impedance setting	21
Turning on the power	22
BASIC SETUP	23
Using the BASIC SETUP menu	23

BASIC OPERATION	
PLAYBACK	26
Basic operations	26
Selecting sound field programs	28
Selecting input modes	32
FM/AM TUNING	34
Automatic and manual tuning	
Presetting stations	
Selecting preset stations	
Exchanging preset stations	
XM SATELLITE RADIO TUNING	
What is XM Satellite Radio?	40
XM Satellite Radio connections	40
XM Satellite Radio functions	41
Activating XM Satellite Radio	42
Basic XM Satellite Radio operations	43
XM Satellite Radio search modes	44
Setting XM Satellite Radio preset channels	47
RECORDING	50

SOUND FIELD PROGRAMS		
SOUND FIELD PROGRAM		
DESCRIPTIONS	51	
For movie/video sources	51	
For music sources	53	

ADVANCED OPERATION	
ADVANCED OPERATIONS	54
Using the sleep timer	54
Manually adjusting speaker levels	55
SET MENU	56
Using SET MENU	
1 SOUND MENU	
2 INPUT MENU	60
3 OPTION MENU	61
ADVANCED SETUP MENU	63
REMOTE CONTROL FEATURES	65
Control area	65
Setting remote control codes	66
Controlling other components	67
Switching library codes <except for="" htr-5840:<="" td=""><td></td></except>	
U.K. and Europe models>	68
Clearing set up remote control codes	68

ADDITIONAL INFORMATION	
EDITING SOUND FIELD PARAMETERS.	69
What is a sound field	69
Changing parameter settings	69
SOUND FIELD PARAMETER	
DESCRIPTIONS	71
TROUBLESHOOTING	73
RESETTING THE FACTORY PRESETS	77
GLOSSARY	78
Audio formats	78
Sound field programs	
Audio information	
Video signal information	80
SPECIFICATIONS	

#### **FEATURES**

#### **Built-in 6-channel power amplifier**

Minimum RMS output power

#### [HTR-5850]

 $(0.06\% \text{ THD}, 20 \text{ Hz to } 20 \text{ kHz}, 8 \Omega)$ 

Front: 90 W + 90 W Center: 90 W

Surround: 90 W + 90 W Surround back: 90 W

#### [HTR-5840]

 $(0.06\% \text{ THD}, 20 \text{ Hz to } 20 \text{ kHz}, 8 \Omega)$ 

Front: 85 W + 85 W Center: 85 W

Surround: 85 W + 85 W Surround back: 85 W

#### Sound field features

- Proprietary YAMAHA technology for the creation of sound fields
- ◆ Dolby Digital/Dolby Digital EX decoder
- DTS/DTS-ES Matrix 6.1, Discrete 6.1, DTS Neo:6, DTS 96/24 decoder
- Dolby Pro Logic/Dolby Pro Logic II/ Dolby Pro Logic IIx decoder
- ♦ Virtual CINEMA DSP
- ◆ SILENT CINEMA™

#### Sophisticated AM/FM tuner

- ◆ 40-station random and direct preset tuning
- Automatic preset tuning
- Preset station shifting capability (preset editing)

#### XM Satellite Radio

 XM Satellite Radio programming (using the "XM Connect and Play digital antenna", sold separately)

#### Other features

- ◆ 192-kHz/24-bit D/A converter
- A SET MENU that provides you with items for optimizing this unit for your audio/video system
- ◆ 6 additional input jacks for discrete multi-channel input
- ◆ S-video signal input/output capability
- ◆ Component video input/output capability
- ◆ Optical and coaxial digital audio signal jacks
- Sleep timer
- ◆ Cinema and music night listening modes
- ◆ Remote control with preset remote control codes

#### [HTR-5850]

- lacktriangle Video signal conversion (Composite video  $\leftrightarrow$  S-video
  - → Component video) capability for monitor out
- This document is the owner's manual for both HTR-5850 and HTR-5840. Model names are given where the details of functions are unique to each model. Illustrations for HTR-5850 are mainly used for explanations.
- y indicates a tip for your operation.
- Some operations can be performed by using either the buttons on the main unit or on the remote control. In cases when the button names differ between the main unit and the remote control, the button name on the remote control is given in parentheses.
- This manual is printed prior to production. Design and specifications are subject to change in part as a result of improvements, etc. In case of differences between the manual and product, the product has priority.

## DOLBY DIGITAL • EX PRO LOGIC IX

Manufactured under license from Dolby Laboratories.

"Dolby", "Pro Logic", "Surround EX", and the double-D symbol are trademarks of Dolby Laboratories.

SILENT ™ CINEMA

"SILENT CINEMA" is a trademark of YAMAHA CORPORATION.



"DTS", "DTS-ES", "Neo:6" and "DTS 96/24" are trademarks of Digital Theater Systems, Inc.




The XM name and related logos are registered trademarks of XM Satellite Radio Inc.

## **GETTING STARTED**


## Supplied accessories

Please check that you received all of the following parts.

#### Remote control







AM loop antenna



75-ohm/300-ohm antenna adapter (U.K. model only)




Indoor FM antenna (U.S.A., Canada and China models)



Indoor FM antenna (U.K., Europe, Australia and Korea models)



## Installing batteries in the remote control



- 1 Press the ▼ part and slide the battery compartment cover off.
- Insert four supplied batteries (AAA, R03, UM-4) according to the polarity markings (+ / -) on the inside of the battery compartment.
- 3 Slide the cover back until it snaps into place.


#### Notes on batteries

- Change all of the batteries if you notice the following conditions; the operation range of the remote control decreases, the indicator does not flash or its light becomes dim.
- Do not use old batteries together with new ones.
- Do not use different types of batteries (such as alkaline and manganese batteries) together. Read the packaging carefully as these different types of batteries may have the same shape and color.
- If the batteries have leaked, dispose of them immediately. Avoid touching the leaked material or letting it come into contact with clothing, etc. Clean the battery compartment thoroughly before installing new batteries.
- Do not throw away batteries with general house waste; dispose
  of them correctly in accordance with your local regulations.

If the remote control is without batteries for more than 2 minutes, or if exhausted batteries remain in the remote control, the contents of the memory may be cleared. When the memory is cleared, insert new batteries, set up the remote control code and program any acquired functions that may have been cleared.

## **CONTROLS AND FUNCTIONS**

#### Front panel



#### 1 STANDBY/ON

Turns on this unit or sets it to the standby mode. When you turn on this unit, you will hear a click and there will be a 4 to 5-second delay before this unit can reproduce sound.

#### Note

In standby mode, this unit consumes a small amount of power in order to receive infrared-signals from the remote control.

#### 2 Remote control sensor

Receives signals from the remote control.

#### 3 Front panel display

Shows information about the operational status of this unit.

#### 4 PRESET/TUNING (EDIT), SEARCH MODE\*

Switches the function of PRESET/TUNING/  $CH^* \mid / h$ , LEVEL -/+ between selecting preset station numbers and tuning.

#### 5 FM/AM, XM\*

Switches the reception band when the unit is in tuner mode.

#### 6 A/B/C/D/E, NEXT, CATEGORY\*

Selects one of the 5 preset station groups (A to E) when the unit is in tuner mode.

Selects the speaker channel to be adjusted when the unit is not in tuner mode.

#### 7 PRESET/TUNING/CH\* | /h, LEVEL -/+

Selects preset station number 1 to 8 when the colon (:) is displayed next to the band indication in the front panel display when the unit is in tuner mode. Selects the tuning frequency when the colon (:) is not displayed. Adjusts the level of the speaker channel selected using A/B/C/D/E (NEXT) when the unit is not in tuner mode.

#### 8 MEMORY (MAN'L/AUTO FM)

Stores a station in the memory. Hold down this button for more than 3 seconds to start automatic preset tuning.

#### TUNING MODE (AUTO/MAN'L MONO), DISPLAY\*

Switches between automatic tuning (AUTO indicator on) and manual tuning (AUTO indicator off).

#### O VIDEO AUX jacks

Input audio and video signals from a portable external source such as a game console. To reproduce source signals from these jacks, select V-AUX as the input source.

#### A VOLUME

Controls the output level of all audio channels. This does not affect the REC OUT level.

#### B OPHONES (SILENT CINEMA) jack

Outputs audio signals for private listening with headphones. When you connect headphones, no signals are output to the OUTPUT jacks or to the speakers. All Dolby Digital and DTS audio signals are mixed down to the left and right headphone channels.

#### C SPEAKERS A/B

Turns on or off the set of front speakers connected to the A and/or B terminals on the rear panel each time the corresponding button is pressed.

#### D STRAIGHT (EFFECT)

Switches the sound fields off or on. When STRAIGHT is selected, input signals (2-channel or multi-channel) are output directly from their respective speakers without effect processing.

#### **E TONE CONTROL**

Use to adjust the bass/treble balance for the front left and right speakers (see page 27).

#### F BASS/TREBLE -/+

Use to adjust the bass/treble balance for the front left and right speakers (in conjunction with TONE CONTROL).

#### G PROGRAM | /h

Use to select sound field programs (see page 27).

#### H INPUT MODE

Sets the priority (AUTO, DTS, ANALOG) for the type of signals received when one component is connected to two or more of this unit's input jacks (see page 32).

#### | INPUT selector

Selects the input source you want to listen to or watch.


#### J MULTI CH INPUT

Selects the source connected to the MULTI CH INPUT jacks. When selected, the MULTI CH INPUT source takes priority over the source selected with INPUT (or the input selector buttons on the remote control).

 Available only when the unit is in the XM Satellite Radio mode (see page 41).

#### Remote control

This section describes the function of each control on the remote control used to control this unit. To operate other components, see "REMOTE CONTROL FEATURES" on page 65.



#### 1 Infrared window

Outputs infrared control signals. Aim this window at the component you want to operate.

#### 2 CODE SET

Use to set up remote control codes (see page 66).

#### 3 Input selector buttons

Select the input source and change the control area.

#### 4 Sound field program/numeric buttons

Use to select sound field programs.

Use numbers 1 through 8 to select preset stations when the unit is in tuner mode.

Use SELECT to playback 2-channel sources in surround (see page 30).

Use EXTD SUR. to switch between 5.1 or 6.1-channel playback of multi-channel software (see page 29). Use DIRECT ST. to playback 2-channel sources in high fidelity sound (see page 31).

#### **5 SPEAKERS A/B**

Use to turn on or off the set of front speakers connected to the A and/or B terminals on the rear panel each time the corresponding button is pressed.

#### 6 NIGHT

Turns on or off the night listening modes (see page 31).

#### 7 LEVEL, BAND

Selects the speaker channel to be adjusted and sets the level

Switches the reception band when the unit is in tuner mode.

#### 8 Cursor buttons u / d / j / i /ENTER

Use to select and adjust sound field program parameters or SET MENU items.

Press  $j \ / \ i$  to select a preset station group (A to E) when the unit is in tuner mode.

Press U / Cl to select a preset station number (1 to 8) when the unit is in tuner mode.

#### 9 RETURN. MEMORY\*

Returns to the previous menu level when adjusting the SET MENU parameters.

#### ○ TRANSMIT indicator

Flashes while the remote control is sending signals.

#### A STANDBY

Sets this unit in the standby mode.

#### **B SYSTEM POWER**

Turns on the power of this unit.

#### C SLEEP

Sets the sleep timer.

#### D MULTI CH IN

Selects multi-channel input when using an external decoder (etc.).

#### E AMP

Selects the AMP mode. You must select the AMP mode to control the main unit.

#### F VOLUME +/-

Increases or decreases the volume level.

#### G MUTE

Mutes the sound. Press again to restore the audio output to the previous volume level.

#### **⊢** STRAIGHT (EFFECT), ENT.\*

Switches the sound fields off or on. When STRAIGHT is selected, input signals (2-channel or multi-channel) are output directly from their respective speakers without effect processing.

#### I SET MENU, SRCH MODE\*


Activates the SET MENU function.

Selects preset station groups when the unit is in tuner mode

\* Available only when the unit is in the XM Satellite Radio mode (see page 41).

## Using the remote control


The remote control transmits a directional infrared beam. Be sure to aim the remote control directly at the remote control sensor on the main unit during operation.



#### Handling the remote control

- Do not spill water or other liquids on the remote control
- Do not drop the remote control.
- Do not leave or store the remote control in the following types of conditions:
  - places of high humidity, such as near a bath
  - places of high temperature, such as near a heater or stove
  - extremely low temperatures
  - dusty places

#### Front panel display



#### 1 Decoder indicators

When any of this unit's decoders function, the respective indicator lights up.

#### 2 VIRTUAL indicator

Lights up when Virtual CINEMA DSP is active (see page 32).

#### 3 SILENT CINEMA indicator


Lights up when headphones are connected and a sound field program is selected (see page 27).

#### 4 Input source indicators

A cursor lights to show the current input source.

#### 5 Sound field indicators

Light to indicate the active DSP sound fields.





Surround back DSP sound field

#### **6 CINEMA DSP indicator**

Lights up when you select a CINEMA DSP sound field program.

#### 7 AUTO indicator

Lights up to indicate that automatic tuning is possible.

#### 8 TUNED indicator

Lights up when this unit is tuned into a station.

#### 9 STEREO indicator

Lights up when this unit is receiving a strong signal for an FM stereo broadcast while the AUTO indicator is lit.

#### O MEMORY indicator

Flashes to show that a station can be stored.

#### A MUTE indicator

Flashes while the MUTE function is on.

#### B VOLUME level indication

Indicates the current volume level.

#### C PCM indicator

Lights up when this unit is reproducing PCM (Pulse Code Modulation) digital audio signals.

#### □ STANDARD indicator

Lights up when Surround Standard or Surround Enhanced is selected (see page 30).

#### E NIGHT indicator

Lights up when you select night listening mode.

#### F SP A B indicators

Light up according to the set of front speakers selected. Both indicators light up when both sets of speakers are selected.

#### G Headphones indicator

Lights up when headphones are connected.

#### **⊢** HiFi DSP indicator

Lights up when you select a HiFi DSP sound field program.

#### Multi-information display

Shows the current sound field program name and other information when adjusting or changing settings.

#### J SLEEP indicator

Lights up while the sleep timer is on.

#### K 96/24 indicator

Lights up when a DTS 96/24 signal is input to this unit.

#### 


Lights up when the input signal contains the LFE signal.

#### M Input channel indicators/speaker indicators

Indicate the channel components of the current digital input signal.

Indicate the number of speakers connected in SPEAKERS (page 24), or indicate the channel being adjusted in SP LEVEL (page 59).

#### Rear panel



#### 1 DIGITAL OUTPUT jack (HTR-5850 only)

See page 19 for connection information.

#### 2 MULTI CH INPUT jacks

See page 17 for connection information.

#### 3 SYSTEM CONNECTOR jack (HTR-5850: U.S.A. and Canada models only)

Use to connect a YAMAHA subwoofer equipped with a SYSTEM CONNECTOR jack to this unit (see page 13).

#### 4 Video component jacks

See pages 16 and 18 for connection information.

#### **5** Antenna terminals

See page 20 for connection information.

#### 6 XM jack

See page 40 for connection information.

#### 7 AC OUTLET(S)

Use to supply power to your other A/V components (see page 21).

## 8 DIGITAL INPUT jacks (MD/CD-R jack is for HTR-5850 only)

See pages 16, 18 and 19 for details.

#### 9 Audio component jacks

See page 19 for connection information.

#### O SUBWOOFER OUTPUT jack

See page 13 for connection information.

#### A Speaker terminals


See page 13 for connection information.


## **SPEAKER SETUP**

#### Speaker placement

The speaker layout below shows the standard ITU-R\* speaker setting. You can use it to enjoy CINEMA DSP and multi-channel audio sources.

\* ITU-R is the radio communication sector of the ITU (International Telecommunication Union).





#### Front speakers (FR and FL)

The front speakers are used for the main source sound plus effect sounds. Place these speakers an equal distance from the ideal listening position. The distance of each speaker from each side of the video monitor should be the same.

#### Center speaker (C)

The center speaker is for the center channel sounds (dialog, vocals, etc.). If for some reason it is not practical to use a center speaker, you can do without it. Best results, however, are obtained with the full system. Align the front face of the center speaker with the front face of your video monitor. Place the speaker centrally between the front speakers and as close to the monitor as possible, such as directly over or under it.

#### Surround speakers (SR and SL)

The surround speakers are used for effect and surround sounds. Place these speakers behind your listening position, facing slightly inwards, about 1.8 m (6 ft) above the floor.

#### Surround back speaker (SB)

The surround back speaker supplements the surround speakers and provides for more realistic front-to-back transitions. Place this speaker directly behind the listening position and at the same height as the surround speakers.

#### Subwoofer

The use of a subwoofer, such as the YAMAHA Active Servo Processing Subwoofer System, is effective not only for reinforcing bass frequencies from any or all channels, but also for high fidelity reproduction of the LFE (low-frequency effect) channel included in Dolby Digital and DTS software. The position of the subwoofer is not so critical, because low bass sounds are not highly directional. But it is better to place the subwoofer near the front speakers. Turn it slightly toward the center of the room to reduce wall reflections.


#### Speaker connections

Be sure to connect the left channel (L), right channel (R), "+" (red) and "-" (black) properly. If the connections are faulty, no sound will be heard from the speakers, and if the polarity of the speaker connections is incorrect, the sound will be unnatural and lack bass.

#### **CAUTION**


- If you will use 4 or 6 ohm speakers, be sure to set this unit's speaker impedance setting to 4 ohms before using (see page 21).
- Before connecting the speakers, make sure that the power of this unit is off.
- Do not let the bare speaker wires touch each other or do not let them touch any metal part of this unit. This could damage this unit and/or speakers.
- Use magnetically shielded speakers. If this type of speakers still creates the interference with the monitor, place the speakers away from the monitor.

A speaker cord is actually a pair of insulated cables running side by side. One cable is colored or shaped differently, perhaps with a stripe, groove or ridges. Connect the striped (grooved, etc.) cable to the "+" (red) terminals on this unit and your speaker. Connect the plain cable to the "-" (black) terminals.



- 1 Remove approximately 10 mm (3/8") of insulation from the end of each speaker cable.
- 2 Twist the exposed wires of the cable together to prevent short circuits.
- 3 Unscrew the knob.
- Insert one bare wire into the hole in the side of each terminal.


#### 5 Tighten the knob to secure the wire.




Red: positive (+)
Black: negative (-)

#### ■ Banana plug connections

(With the exception of U.K. and Europe models) First, tighten the knob and then insert the banana plug connector into the end of the corresponding terminal.





#### ■ FRONT terminals

Connect one or two speaker systems (2, 3) to these terminals. If you use only one speaker system, connect it to the FRONT A or B terminals.

#### ■ CENTER terminals

Connect a center speaker (4) to these terminals.

#### SURROUND terminals

Connect surround speakers (6, 7) to these terminals.

#### ■ SUBWOOFER jack


Connect a subwoofer with built-in amplifier (1), such as the YAMAHA Active Servo Processing Subwoofer System, to this jack.

#### SYSTEM CONNECTOR jack (HTR-5850: U.S.A. and Canada models only)

Use this jack to control the power of your Yamaha subwoofer if a system connector jack is available on the subwoofer.

#### SURROUND BACK terminals

Connect a surround back speaker (5) to these terminals.



Speaker layout


#### **CONNECTIONS**

#### Before connecting components

#### **CAUTION**

Do not connect this unit or other components to the mains power until all connections between components are complete.

#### Cable indications



#### Analog jacks

You can input analog signals from audio components by connecting audio pin cable to the analog jacks on this unit. Connect red plugs to the right jacks and white plugs to the left jacks.

#### ■ Digital jacks

This unit has digital jacks for direct transmission of digital signals through either coaxial or fiber optic cables. You can use the digital jacks to input PCM, Dolby Digital and DTS bitstreams. When you connect components to both the COAXIAL and OPTICAL jacks, priority is given to the input signals from the COAXIAL jack. All digital input jacks are compatible with 96-kHz sampling digital signals.

#### Note

This unit handles digital and analog signals independently. Thus audio signals input to the analog jacks are only output to the analog OUT (REC) jacks.

#### **Dust protection cap**

Pull out the cap from the optical jack before you connect the fiber optic cable. Do not discard the cap. When you are not using the optical jack, be sure to put the cap back in place. This cap protects the jack from dust.



This unit has three types of video jacks. Connection depends on the availability of input jacks on your monitor.

#### [HTR-5850 only]

The signals input through the S VIDEO jacks on HTR-5850 are automatically converted for output through the VIDEO jacks. When V. CONV. is set to ON (see page 59), signals input through the VIDEO jacks can be output through the S VIDEO jacks.







#### VIDEO jacks


For conventional composite video signals.

#### S VIDEO jacks

For S-video signals, separated into luminance (Y) and color (C) video signals to achieve high-quality color reproduction.

#### **COMPONENT VIDEO jacks**

For component signals, separated into luminance (Y) and color difference  $(P_B, P_R)$  to provide the best quality in picture reproduction.



#### Note

#### [HTR-5850 only]

When signals are input through both the S VIDEO and VIDEO jacks, signals input through the S VIDEO jack have priority.


## Connecting video components

#### ■ Connections for DVD playback

#### Note

For HTR-5840, be sure to connect your video source components in the same way you connect your video monitor to HTR-5840. For HTR-5850, be sure to connect your video source components in the same way you connect your video monitor to HTR-5850 if VIDEO CONV. (see page 59) is set to OFF. (Even when V.CONV is set to OFF, S-video signals input from your video source component are automatically converted to composite signals in this unit.)


For example, if you connect your video monitor to this unit using a VIDEO connection, connect your video source components to this unit using the VIDEO connections.



#### **■** Connecting to the MULTI CH INPUT jacks

This unit is equipped with 6 additional input jacks (left and right FRONT, CENTER, left and right SURROUND and SUBWOOFER) for discrete multi-channel input from a multi-format player, external decoder, sound processor or preamplifier.

Connect the output jacks on your multi-format player or external decoder to the MULTI CH INPUT jacks. Be sure to match the left and right outputs to the left and right input jacks for the front and surround channels.




#### Notes

- When you select MULTI CH INPUT as the input source, this unit automatically turns off the digital sound field processor, and you cannot select sound field programs.
- This unit does not redirect signals input to the MULTI CH INPUT jacks to accommodate for missing speakers. We recommend that you connect at least a 5.1-channel speaker system before using this feature.
- When headphones are used, only front left and right channels are output.

#### ■ Connections for other video components


#### Notes

- For HTR-5840, be sure to connect your video source components in the same way you connect your video monitor to HTR-5840.
   For HTR-5850, be sure to connect your video source components in the same way you connect your video monitor to HTR-5850 if VIDEO CONV. (see page 59) is set to OFF. (Even when V.CONV is set to OFF, S-video signals input from your video source component are automatically converted to composite signals in this unit.)
- For example, if you connect your video monitor to this unit using a VIDEO connection, connect your video source components to this unit using the VIDEO connections.
- Converted video signals are only output to the MONITOR OUT jacks. When recording you must make the same type of video connections (i.e., S-video) between each component.



#### ■ VIDEO AUX jacks (on the front panel)

Use these jacks to connect any video source, such as a game console or video camera, to this unit.




## **Connecting audio components**

#### ■ Connections for audio components

#### Note

DIGITAL OUTPUT (MD/CD-R) jack and DIGITAL INPUT (MD/CD-R) jack are not equipped with HTR-5840. To connect a MD recorder or tape deck to HTR-5840, use the analog connections (AUDIO OUT/IN).



# Connecting the FM and AM antennas

Both FM and AM indoor antennas are included with this unit. In general, these antennas should provide sufficient signal strength. Connect each antenna correctly to the designated terminals.

# AM loop antenna (included) AM loop antenna (included) (HTR-5850 U.S.A. model) Ground (GND terminal) For maximum safety and minimum interference, connect the antenna GND terminal to a good earth ground. A good earth ground is a metal stake driven into moist earth.

3 Orient the AM loop antenna for the best reception.




#### Notes

- The AM loop antenna should be placed away from this unit.
- The AM loop antenna should always be connected, even if an outdoor AM antenna is connected to this unit.
- A properly installed outdoor antenna provides clearer reception than an indoor one. If you experience poor reception quality, an outdoor antenna may improve the quality. Consult the nearest authorized YAMAHA dealer or service center about outdoor antennas.

#### ■ Connecting the AM loop antenna

1 Set up the AM loop antenna, then connect it to the terminals on this unit.



Press and hold the tab to insert the AM loop antenna lead wires into the AM ANT and GND terminals.



#### Connecting the power supply cord

#### ■ Connecting the AC power cord

Plug the power cord into an AC wall outlet.

#### ■ AC OUTLET(S) (SWITCHED)

U.K. and Australia models	1 outlet
Korea model	None
Other models	2 outlets

Use these outlets to connect the power cords from your other components to this unit. Power to the AC OUTLET(S) is controlled by this unit's STANDBY/ON (or SYSTEM POWER and STANDBY). The outlet(s) supply power to any connected component whenever this unit is turned on. For information on the maximum power (total power consumption of components), see "SPECIFICATIONS" on page 81.

#### ■ Memory back-up

The memory back-up circuit prevents the stored data from being lost even if this unit is in the standby mode. However if the power cord is disconnected from the AC wall outlet, or the power supply is cut for more than one week, the stored data will be lost.

#### Speaker impedance setting

#### **CAUTION**

If you are using 4 or 6 ohm speakers, set the impedance to 4 or 6 ohms as follows before turning on the power.

Be sure this unit is in the standby mode.

1 Turn off the power to this unit, and while holding down STRAIGHT (EFFECT), press STANDBY/ON.

This unit turns on, and the ADVANCED SETUP menu appears in the front panel display.



While holding down, press



2 Press PROGRAM | / h to move through the menu and select "SP IMP.".



3 Press STRAIGHT (EFFECT) repeatedly to select " $4\Omega$  MIN".



4 Press STANDBY/ON to turn off the power.





The setting you made is reflected the next time this unit's power is turned on.

## Turning on the power

When all connections are complete, turn on the power of this unit.

(U.S.A. model)





Press STANDBY/ON (or SYSTEM POWER on the remote control) to turn on the power of this unit.



or



Front panel

Remote control

#### **BASIC SETUP**

The basic setup feature is a useful way to set up your system quickly and with minimal effort.


- y
   If you wish to configure the unit manually using more precise


  ... SOUND MENU adjustments, use the detailed parameters in SOUND MENU (page 58) instead of using BASIC SETUP.
- Altering any parameters in BASIC SETUP will reset all parameters in SOUND MENU.
- Initial settings are indicated in bold for each parameter.

#### Using the BASIC SETUP menu

Before you begin:

- Press SPEAKERS A or B on the front panel (or press AMP to select the AMP mode, then press SPEAKERS A or B on the remote control) to select the front speakers you want to use.
- Make sure you disconnect your headphones from this





Press AMP.



#### Press SET MENU.


"BASIC SETUP" appears in the front panel display.





BASIC SETUP

#### Press ENTER to enter BASIC SETUP.



The ROOM parameter appears in the front panel display.

#### Press j / i to select the desired setting.

ROOM: S M >L

Select the size of the room you have installed your speakers in. In general, the room sizes are defined as follows:


[U.S.A. and Canada models]

16 x 13ft, 200ft<sup>2</sup> (4.8 x 4.0m, 20m<sup>2</sup>) S (small) **M (medium)** 20 x 16ft, 300ft<sup>2</sup> (6.3 x 5.0m, 30m<sup>2</sup>) 26 x 19ft, 450ft<sup>2</sup> (7.9 x 5.8m, 45m<sup>2</sup>) L (large)

[Other models]

S (small) 3.6 x 2.8m, 10m<sup>2</sup> **M (medium)** 4.8 x 4.0m, 20m<sup>2</sup> 6.3 x 5.0m, 30m<sup>2</sup> L (large)

#### Press d to display the SUBWOOFER parameter.




#### Press j / i to select the desired setting.

#### SUBWOOFER ·· YES

YES If you have a subwoofer in your system. NONE If you do not have a subwoofer in your system.

## 7 Press d to display the SPEAKERS parameter.




## 8 Press j / i to select the number of speakers you connected.

#### SPEAKERS..6spk

Choices	Display	Speakers
2spk	L R	Front L/R
3spk	LCR	Front L/R, Center
4spk	L R SL SR	Front L/R, Surround L/R
5spk	LCR SL SR	Front L/R, Center, Surround L/R
6spk	LCR SLSB SR	Front L/R, Center, Surround L/R, Surround back

#### 9 Press d to display SET/CANCEL.



#### 10 Press j / i to select the desired setting.

#### >SET CANCEL


**SET** To apply the settings you chose in steps

4 through 8.

CANCEL To cancel the setup without making

any changes.

#### 11 Press ENTER to confirm your selection.



If you selected SET, you hear a test tone from each speaker in turn. "CHECK:TestTone" appears in the front panel display for a few seconds, then "CHECK OK?".

CHECK: TestTone



CHECK OK? YES

#### 12 Press j / i to select the desired setting.


CHECK OK? YES

YES To complete the setup process if the test tone levels from each speaker were satisfactory.

NO To proceed to the SP LEVEL speaker level adjustment menu to balance the level of each

speaker.

#### 13 Press ENTER to confirm your selection.



If you selected NO in step 12, the front speaker level adjustment display appears in the front panel display.

#### ■ To balance the speaker levels

Perform the following steps after step 13 (see page 24).



The unit outputs the test tone from the selected speaker and the left front (or left surround) speaker in turn. The indicator of the speaker currently outputting the test tone flashes in the front panel display.

## 14 Press d / u to select a speaker, then use j / i to adjust the balance.

The control range is from +10 dB to -10 dB.

Adjusts the balance between the front left and right speakers.

Adjusts the balance between the front left and center speakers.

Adjusts the balance between the front left and surround left speakers.

Adjusts the balance between the surround left and surround back speakers.

Adjusts the balance between the surround left and surround right speakers.

Adjusts the balance between the front left speaker and the subwoofer.

## 15 Press SET MENU to exit after balancing the speakers.


#### Memory back-up


The memory back-up circuit prevents the stored data from being lost even if this unit is in the standby mode. However, if the power cord is disconnected from the AC outlet, or the power supply is cut for more than one week, the stored data will be lost. If so, adjust the items again.

#### **PLAYBACK**


#### **Basic operations**

(U.S.A. model)






1 Press STANDBY/ON (or SYSTEM POWER on the remote control) to turn on the power.




- 2 Turn on the video monitor connected to this unit.
- 3 Press SPEAKERS A or B (or press AMP to select the AMP mode, then press SPEAKERS A or B on the remote control).

Each press turns the respective speakers on or off.




#### 4 Select the input source.

Use INPUT (or press one of the input selector buttons on the remote control) to select the input you desire.




The current input source name and input mode appear in the front panel display for a few seconds.



5 Start playback or select a broadcast station on the source component.


Refer to the operating instructions for the component.

6 Adjust the volume to the desired output level.



#### 7 Select a sound field program if desired.

Press PROGRAM | / h repeatedly (or press AMP to select the AMP mode, then press one of the sound field program buttons on the remote control) to select a sound field program. (See page 51 for details about sound field programs.)



Remote control

## ■ To listen with headphones ("SILENT CINEMA")

"SILENT CINEMA" allows you to enjoy multi-channel music or movie sound, including Dolby Digital and DTS surround, through ordinary headphones. "SILENT CINEMA" activates automatically whenever you connect headphones to the PHONES jack while listening to CINEMA DSP or HiFi DSP sound field programs. When activated, the "SILENT CINEMA" indicator lights up in the front panel display.

#### Notes

- This unit will not be set to "SILENT CINEMA" when MULTI CH INPUT is selected as the input source.
- "SILENT CINEMA" is not effective when the Direct Stereo or 2ch Stereo program is selected, or in STRAIGHT mode.

#### ■ To adjust the tone

You can adjust the tonal quality of your front left and right speakers or headphones (when connected).

Press TONE CONTROL on the front panel repeatedly to select TREBLE or BASS, then press BASS/TREBLE —/+ repeatedly to increase or decrease.

- Select TREBLE to adjust the high frequency response.
- Select BASS to adjust the low frequency response.


y Speaker and headphone adjustments are stored independently.

#### Notes

- If you increase or decrease the high-frequency or low-frequency sound to an extreme level, the tonal quality of the surround speakers may not match that of the front left and right speakers.
- TONE CONTROL is not effective with the Direct Stereo program (page 31) or MULTI CH INPUT.
- When TC.BYPASS is set to AUTO (page 60), and BASS and TREBLE are set to 0 dB, audio output automatically bypasses this unit's tone control cicuitry.


#### ■ To mute the sound

Press MUTE on the remote control. The MUTE indicator flashes in the front panel display.




У

You can adjust the muting level (see page 60).



#### ■ Selecting MULTI CH INPUT

Press MULTI CH INPUT (or MULTI CH IN on the remote control) so that "MULTI CH INPUT" appears in the front panel display.




#### Note

When "MULTI CH INPUT" is shown in the front panel display, no other source can be played. To select another input source with INPUT (or one of the input selector buttons), press MULTI CH INPUT (or MULTI CH IN on the remote control) to turn off "MULTI CH INPUT" in the front panel display.

#### Playing video sources in the background

You can combine a video image from a video source with sound from an audio source. For example, you can enjoy listening to classical music while viewing beautiful scenery from the video source on the video monitor.

Use the input selector buttons on the remote control to select a video source, then select an audio source.




#### Note

If you want to enjoy audio from the MULTI CH INPUT jacks together with a video source, first select the video source, then press MULTI CH INPUT (or MULTI CH IN on the remote control).

#### Selecting sound field programs

#### ■ Front panel operation




## Press PROGRAM I / h repeatedly to select the desired program.

The name of the selected program appears in the front panel display.




#### Remote control operation



Press AMP to select the AMP mode, then press one of the sound field program buttons repeatedly to select the desired program.

The name of the selected program appears in the front panel display.



y Choose a sound field program based on your listening preference, and not purely on the name of the program itself.

#### Notes

- When you select an input source, this unit automatically selects the last sound field program used with that source.
- Sound field programs cannot be selected when MULTI CH INPUT is selected.
- Sampling frequencies higher than 48 kHz (except for DTS 96/ 24 signals) will be sampled down to 48 kHz, then sound field programs will be applied.


#### **■** Enjoying multi-channel software

If you connected a surround back speaker, use this feature to enjoy 6.1-channel playback for multi-channel sources using the Dolby Pro Logic IIx, Dolby Digital EX or DTS-ES decoders.

Press AMP on the remote control to select the AMP mode, then press EXTD SUR. to switch between 5.1 and 6.1-channel playback.



To select a decoder, press j / i repeatedly while PLIIxMusic (etc.) is displayed.



#### Auto (AUTO)

When a signal (flag) that can be recognized by the unit is input, the unit selects the optimum decoder for playing back the signal in 6.1 channels.

If the unit cannot recognize the flag or no flag is present in the input signal, it cannot automatically be played in 6.1 channels.

#### Decoders (select with j / i)

You can select from the following decoders depending on the format of the software you are playing.

PLII xMusi c

For playing back Dolby Digital or DTS signals in 6.1 channels using the Pro Logic IIx music decoder.

EX/ES

For playing back Dolby Digital signals in 6.1 channels using the Dolby Digital EX decoder.

DTS signals are played back in 6.1 channels using the DTS-ES decoder.

EX

For playing back Dolby Digital or DTS signals in 6.1 channels using the Dolby Digital EX decoder.

#### Off (OFF)

Decoders are not used to create 6.1 channels.

#### Notes

- Some 6.1-channel compatible discs do not have a signal (flag) which this unit can automatically detect. When playing these kinds of discs with 6.1-channel, select a decoder manually (PLIIx Music, EX/ES or EX).
- 6.1-channel playback is not possible even if EXTD SUR. is pressed in the following cases:
  - When "SUR. LR" (see page 58) or "SUR. B" (see page 58) is set to NONE.
  - When the source connected to the MULTI CH INPUT jack is being played.
  - When the source being played does not contain surround left and right channel signals.
- When a Dolby Digital KARAOKE source is being played.
- When "2ch Stereo" or "Direct Stereo" is selected.
- When the power of this unit is turned off, this setting will be reset to "AUTO".
- The Pro Logic IIx decoder is not available when "SUR. B" is set to NONE (see page 58).

#### ■ Enjoying 2-channel software in surround

Signals input from 2-channel sources can also be played back on multiple channels.

Press AMP to select the AMP mode, then press STANDARD on the remote control to switch between the SUR. STANDARD and SUR. ENHANCED programs.



Or press MOVIE to select the MOVIE THEATER program.



Press SELECT on the remote control to select the decoder.



You can select from the following modes depending on the type of software you are playing and your personal preference.

#### When you select the SUR. STANDARD program:

PRO LOGIC

Dolby Pro Logic processing for any sources.

PLII Movie

Dolby Pro Logic II processing for movie software.

PLII Music

Dolby Pro Logic II processing for music software.

PLII Game

Dolby Pro Logic II processing for game software.

PLIIx Movie

Dolby Pro Logic IIx processing for movie software.

PLIIx Music

Dolby Pro Logic IIx processing for music software.

PLIIx Game

Dolby Pro Logic IIx processing for game software.

Neo: 6 Ci nema

DTS processing for movie software.

Neo: 6 Musi c

DTS processing for music software.

## When you select the SUR. ENHANCED or MOVIE THEATER program:

PRO LOGIC

Dolby Pro Logic processing for any sources.

PLII Movie

Dolby Pro Logic II processing for movie software.

PLIIx Movie

Dolby Pro Logic IIx processing for movie software.

Neo: 6 Ci nema

DTS processing for movie software.

У

You can also select a decoder by pressing j / i on the remote control when the decoder type is displayed in the front panel display.


#### Note

The Pro Logic IIx decoder is not available when "SUR. B" is set to NONE (see page 58).

#### Listening to high fidelity stereo sound (Direct Stereo)

Direct Stereo allows you to bypass this unit's decoders and DSP processors to enjoy pure high fidelity sound from 2-channel PCM and analog sources.

Press PROGRAM | / h repeatedly (or press AMP to select the AMP mode, then press DIRECT ST.) to select "Direct Stereo".



#### Notes

- To avoid unexpected noise, do not play DTS-encoded CDs in this mode.
- When multi-channel signals (Dolby Digital and DTS) are input, this unit automatically switches to the corresponding analog input. (When DTS is selected as an input mode, no sound will be heard.)
- · No sound will be output from the subwoofer.
- TONE CONTROL (page 27) and SET MENU (page 56) settings are not effective.
- · The front panel display automatically dims.
- If you press AMP on the remote control to select the AMP mode, then press DIRECT ST., the unit automatically enters Direct Stereo mode and you cannot toggle between the unit's other sound field programs.

#### ■ Night listening modes

The night listening modes are designed to improve listenability at lower volumes or at night. Choose either NIGHT:CINEMA or NIGHT:MUSIC depending on the type of material you are playing.

# Press AMP to select the AMP mode, then press NIGHT repeatedly on the remote control to select cinema or music.


When night listening is selected, the NIGHT indicator in the front panel display lights up.



- Select NIGHT:CINEMA when watching films to reduce the dynamic range of film soundtracks and make dialog easier to hear at lower volumes.
- Select NIGHT:MUSIC when listening to music sources to preserve ease-of-listening for all sounds.
- Select OFF if you do not want to use this function.

## Press j / i to adjust the effect level while NIGHT:CINEMA or NIGHT:MUSIC is displayed.

This adjusts the level of compression.



Remote control

Effect. LvI: MID

- Select MIN for minimum compression.
- Select MID for standard compression.
- Select MAX for maximum compression.

y NIGHT:CINEMA and NIGHT:MUSIC adjustments are stored independently.


#### Notes

- You cannot use the night listening modes with the Direct Stereo program or MULTI CH INPUT (even though the NIGHT indicator lights up when Direct Stereo is selected).
- The night listening modes may vary in effectiveness depending on the input source and surround sound settings you use.

#### Downmixing to 2 channels

You can enjoy 2-channel stereo playback even from multichannel sources.

Press PROGRAM | / h repeatedly (or press AMP to select the AMP mode, then press STEREO on the remote control) to select 2ch Stereo.




#### 2ch Stereo

y You can use a subwoofer with this program when SWFR or BOTH is selected in "BASS OUT".

#### ■ Listening to unprocessed input signals

In STRAIGHT mode, two channel stereo sources are output from only the front left and right speakers. Multichannel sources are decoded straight into the appropriate channels without any additional effect processing.

Press STRAIGHT (or press AMP to select the AMP mode, then press STRAIGHT on the remote control) to select STRAIGHT.



STRAI GHT

Press STRAIGHT (EFFECT) again so that "STRAIGHT" disappears from the display when you want to turn the sound effect back on.

#### ■ Virtual CINEMA DSP

Virtual CINEMA DSP allows you to enjoy the CINEMA DSP programs without surround speakers. It creates virtual speakers to reproduce the natural sound field. If you set "SUR. LR" to NONE (see page 58), Virtual CINEMA DSP activates automatically whenever you select a CINEMA DSP sound field program.

#### Note

Virtual CINEMA DSP will not activate, even when "SUR. LR" is set to NONE (see page 58) in the following cases:

- When MULTI CH INPUT is selected as the input source.
- When headphones are connected to the PHONES jack.


#### Selecting input modes

This unit comes with a variety of input jacks. Do the following to select the type of input signals you want to

1 Rotate INPUT to select the input source.



2 Press INPUT MODE to select an input mode. In most cases, use AUTO.



AUTO Automatically selects input signals in

the following order:

1) Digital signals\*2) Analog signals

DTS Selects only digital signals encoded in DTS. If no DTS signals are input, no

sound is output.

ANALOG Selects only analog signals. If no

analog signals are input, no sound is output.

\* If this unit detects a Dolby Digital or DTS signal, the decoder automatically switches to the appropriate decoder.

You can adjust the default input mode of this unit (see page 61).


#### Notes

- When playing a DTS-CD/LD, be sure to set the IMPUT MODE to DTS
- If the digital output data of the player has been processed in any way, you may not be able to perform DTS decoding even if you make a digital connection between this unit and the player depending on the player.


# ■ Displaying information about the input

You can display the type, format and sampling frequency of the current input signal.


### 1 Select the input source.



Press AMP to select the AMP mode, then press STRAIGHT so that "STRAIGHT" appears in the display.



3 Press u / d to display the following information about the input signal.



(Format) Signal format display. When the unit cannot detect a digital signal it automatically switches to analog input. i n Number of source channels in the input signal. For example, a multi-channel soundtrack with 3 front channels, 2 surround channels and LFE, is displayed as "3/2/LFE". fs Sampling frequency. When the unit is unable to detect the sampling frequency "Unknown" appears. Bit rate. When the unit is unable to rate detect the bit rate "Unknown" appears. fl g Flag data encoded with DTS or Dolby

Digital signals that cue this unit to

automatically switch decoders.


# **FM/AM TUNING**

# Automatic and manual tuning

There are 2 tuning methods; automatic and manual. Automatic tuning is effective when station signals are strong and there is no interference.

#### Automatic tuning

(U.S.A. model)



1 Rotate INPUT to select TUNER as the input source.



2 Press FM/AM to select the reception band.


"FM" or "AM" appears in the front panel display.



3 Press TUNING MODE (AUTO/MAN'L MONO) so that the AUTO indicator lights up in the front panel display.




If a colon (:) appears in the front panel display, tuning is not possible. Press PRESET/TUNING (EDIT) to turn the colon (:) off.



4 Press PRESET/TUNING/CH | / h once to begin automatic tuning.

Press h to tune into a higher frequency, or press l to tune into a lower frequency.



When tuned into a station, the TUNED indicator lights up and the frequency of the received station is shown in the front panel display.


#### Manual tuning

If the signal from the station you want to select is weak, tune into it manually. Manually tuning into an FM station will automatically switch the tuner to monaural reception to increase the signal quality.

- 1 Select TUNER and the reception band following steps 1 and 2 as described in "Automatic tuning".
- 2 Press TUNING MODE (AUTO/MAN'L MONO) so that the AUTO indicator disappears from the front panel display.



If a colon (:) appears in the front panel display, tuning is not possible. Press PRESET/TUNING (EDIT) to turn the colon (:) off.



# 3 Press PRESET/TUNING/CH | / h to tune into the desired station manually.


Hold down the button to continue searching.



### **Presetting stations**

#### ■ Automatically presetting FM stations

You can use the automatic preset tuning feature to store FM stations. This function enables this unit to automatically tune into FM stations with strong signals, and to store up to 40 (8 stations in 5 groups, A1 through E8) of those stations in order. You can then recall any preset station easily by selecting the preset station number.




1 Press FM/AM to select the FM band.



2 Press TUNING MODE (AUTO/MAN'L MONO) so that the AUTO indicator lights up in the front panel display.




If a colon (:) appears in the front panel display, tuning is not possible. Press PRESET/TUNING (EDIT) to turn the colon (:) off.



# 3 Press and hold MEMORY (MAN'L/AUTO FM) for more than 3 seconds.

The preset number, the MEMORY and AUTO indicators flash. After about 5 seconds, automatic presetting starts from the frequency currently displayed and proceeds toward the higher frequencies.



When automatic preset tuning is completed, the front panel display shows the frequency of the last preset station.

#### Notes

- Any stored station data existing under a preset number is cleared when you store a new station under that preset number.
- If the number of received stations does not reach 40 (E8), automatic preset tuning has automatically stopped after searching all stations.
- Only FM stations with sufficient signal strength are stored automatically by automatic preset tuning. If the station you want to store is weak in signal strength, tune into it manually and store it by following the procedure in "Manually presetting stations".

#### Automatic preset tuning options:

You can select the preset number from which this unit will store FM stations and/or begin tuning toward lower frequencies.

After pressing MEMORY in step 3:

- 1 Press A/B/C/D/E (NEXT), then PRESET/TUNING/ CH | / h to select the preset number under which the first station will be stored. Automatic preset tuning will stop when stations have all been stored up to E8.
- 2 Press PRESET/TUNING (EDIT) to turn off the colon (:) and then press PRESET/TUNING/CH | to begin tuning toward the lower frequencies.


#### Memory back-up

The memory back-up circuit prevents the stored data from being lost even if this unit is set in the standby mode, the power cord is disconnected from the AC outlet, or the power supply is temporarily cut due to power failure. However, if the power is cut for more than one week, the preset stations may be cleared. If so, store the stations again by using the presetting station methods.

#### Manually presetting stations

You can also store up to 40 stations (8 stations x 5 groups) manually.

(U.S.A. model)



#### 1 Tune into a station.


See page 34 for tuning instructions.



When tuned into a station, the front panel display shows the frequency of the station received.


#### 2 Press MEMORY (MAN'L/AUTO FM).

The MEMORY indicator flashes for about 5 seconds.



#### 3 Press A/B/C/D/E (NEXT) repeatedly to select a preset station group (A to E) while the MEMORY indicator is flashing.


The group letter appears. Check that the colon (:) appears in the front panel display.



# 4 Press PRESET/TUNING/CH | / h to select a preset station number (1 to 8) while the MEMORY indicator is flashing.

Press h to select a higher preset station number.

Press l to select a lower preset station number.



# Press MEMORY (MAN'L/AUTO FM) on the front panel while the MEMORY indicator is flashing.

The station band and frequency appear in the front panel display with the preset group and number you have selected.





Shows the displayed station has been stored as C3.


### 6 Repeat steps 1 to 5 to store other stations.


#### Notes

- Any stored station data existing under a preset number is cleared when you store a new station under that preset number.
- The reception mode (stereo or monaural) is stored along with the station frequency.

# Selecting preset stations

You can tune any desired station simply by selecting the preset station number under which it was stored.






Y When performing this operation with the remote control, first press TUNER to set the remote to tuner mode.


# 1 Press A/B/C/D/E (NEXT) (or A-E/CAT. j / i on the remote control) to select the preset station group.

The preset group letter appears in the front panel display and changes each time you press the button.



# 2 Press PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control) to select a preset station number (1 to 8).


The preset group and number appear in the front panel display along with the station band, frequency and the TUNED indicator lights up.



# **Exchanging preset stations**

You can exchange the assignment of two preset stations with each other. The example below describes the procedure for exchanging preset station "E1" with "A5".

(U.S.A. model)




1 Select preset station "E1".

See "Selecting preset stations".


# 2 Press and hold PRESET/TUNING (EDIT) for more than 3 seconds.

"E1" and the MEMORY indicator flash in the front panel display.



# 3 Select preset station "A5" using A/B/C/D/E and PRESET/TUNING/CH | / h.

"A5" and the MEMORY indicator flash in the front panel display.



### 4 Press PRESET/TUNING (EDIT) again.

The stations stored at the two preset assignments are exchanged.



# **XM SATELLITE RADIO TUNING**

#### What is XM Satellite Radio?

XM Satellite Radio is the satellite radio service with millions of listeners across the U.S., broadcasting live daily. XM's channel lineup includes more than 130 digital channels of choice from coast to coast: 68 commercial-free music channels, featuring hip hop to opera, classical to country, bluegrass to blues; 33 channels of premier sports, talk, comedy, children's and entertainment programming; and more than 20 channels of the traffic and weather information for major metropolitan areas nationwide.

Because XM Satellite Radio is a subscription service, you will need to set up an account and activate service with XM using your XM Satellite Radio ID number. To check your ID number, follow "Activating XM Satellite Radio" on page 42. For further information on XM Satellite Radio services, see the XM Satellite Radio website at "http://www.xmradio.com".


#### Notes

- The XM Satellite Radio service is only available in the 48 contiguous United States (not available in Alaska and Hawaii).
- XM Connect and Play digital antenna and monthly subscription are sold separately. For details, see the XM Satellite Radio website at "http://www.xmradio.com".

### XM Satellite Radio connections

# Connecting the XM Connect and Play digital antenna

Connect the XM Connect and Play digital antenna (sold separately) to the XM jack on the rear of this unit. (For details, see the operating instructions provided with the XM Digital Antenna.)



#### **Notes**

- For information on obtaining the XM Connect and Play digital antenna, see the website at "http://www.xmradio.com" or visit your local retailer that sells XM Ready products.
- To ensure optimal reception of XM's satellite signal, the XM
   Connect and Play digital antenna should be placed at or near a
   southerly facing window with nothing obstructing its path to the
   sky. You can mount it indoors or outdoors.

### XM Satellite Radio functions


This section describes the functions of each control used for XM Satellite Radio tuning.

#### Front panel functions

#### Note

The following controls are only available when the unit is in the TUNER mode and the XM Connect and Play digital antenna is connected to the XM jack on the rear of this unit. (For details, see "XM Satellite Radio connections".)

(U.S.A. model)



#### 1 SEARCH MODE

Switches between the All Channel Search, Category Search, and Preset Search modes. (For details, see "XM Satellite Radio search modes" on page 44.)

#### 2 **XM**

Switches the reception band between AM, FM and XM.

#### **3 CATEGORY**

#### (All Channel Search mode)

Changes the channel category to next one (while staying in the All Channel Search mode).

#### (Category Search mode)

Changes the channel category to next one.

#### (Preset Search mode)

Switches between five preset groups (A to E).

# 4 PRESET/TUNING/CH | / h

#### (All Channel Search mode)

Searches a radio channel within all channels. Press and hold for quick search.

#### (Category Search mode)

Searches a radio channel within the selected category. Press and hold for quick search.

#### (Preset Search mode)

Changes the preset number (1 to 8).

#### 5 MEMORY

Switches the unit to the preset memory mode.


#### 6 DISPLAY

Switches XM information such as channel number/name, category or artist name/song title displayed in the front panel display. (For details, see "Switching XM information" on page 43.)

#### ■ Remote control functions

#### Note

The following controls are only available when the unit is in the TUNER mode. To switch to the TUNER mode, press TUNER to select TUNER as the input source.



#### 1 Numeric buttons

#### (All Channel Search or Category Search mode)

Use 1 to 9 and 0 to enter a channel number directly. (Preset Search mode)

Use 1 to 8 to enter a preset channel number directly.

#### 2 BAND

Switches the reception band between the currently selected band (AM or FM) and XM.

# 3 Cursor buttons u / d / j / i (All Channel Search mode)

Press A-E/CAT. j / i to change the channel category. Press PRESET/CH u / d to search a radio channel within all channels. Press and hold for quick search.

#### (Category Search mode)

Press A-E/CAT. j / i to change the channel category.

Press PRESET/CH u / d to search a radio channel within the selected category. Press and hold for quick search.

#### (Preset Search mode)

Press A-E/CAT. j / i to change the preset group (A to E). Press PRESET/CH u / d to change the preset number (1 to 8).

#### 4 MEMORY

Switches the unit to the preset memory mode.

#### 5 **ENT.**

Confirms an entered channel number during the Direct Number Access mode (see page 46).

#### 6 SRCH MODE

Switches between the All Channel Search, Category Search, and Preset Search modes. (For details, see "XM Satellite Radio search modes" on page 44.)


#### 7 DISPLAY

Switches XM information such as channel number/name, category or artist name/song title displayed in the front panel display. (For details, see "Switching XM information" on page 43.)

### Activating XM Satellite Radio

To sign up for an account with the XM Satellite Radio service, an XM Satellite Radio ID number is required. Follow the procedure below to check your ID number, and then access the website at "http://activate.xmradio.com" or call "1-800-XM-RADIO (1-800-967-2346)" with a major credit card for signing up.


(U.S.A. model)



1 Rotate INPUT (or press TUNER on the remote control) to select TUNER as the input source.




2 Press XM (or BAND on the remote control) to select "XM" as the reception band.



If "CHECK ANTENNA" appears in the front panel display, the XM Connect and Play digital antenna may not be connected to the XM jack on the rear of this unit properly. See "XM Satellite Radio connections" on page 40 and check the connection.

3 Press PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control) to select channel "0".



#### Note


You cannot select channel "0" if the "All Channel Search mode" (see page 44) is not selected.

4 Check the XM Satellite Radio ID number displayed in the front panel display and write it down.


ID:			
ID.			

# Basic XM Satellite Radio operations

#### Selecting the XM Satellite Radio mode




1 Rotate INPUT (or press TUNER on the remote control) to select TUNER as the input source.



#### Press XM (or BAND on the remote control) to select "XM" as the reception band.

Information (such as channel number/name, category, or artist name/song title) for the channel currently selected appears in the front panel display and the XM indicator lights up.



V

- Selecting the "XM" band automatically recalls the channel previously selected.
- You can change the kind of XM information by pressing DISPLAY repeatedly. (For details, see "Switching XM information" on page 43.)


#### Note

XM Satellite Radio signals cannot be output from the AUDIO OUT (REC) jacks.

#### Switching XM information

You can display XM information (such as channel number/name, category, or artist name/song title) for the channel currently selected in the front panel display.


Press DISPLAY on the unit (or remote control during the TUNER mode) repeatedly to toggle between the following XM information display modes.




When the channel number/name is displayed:



When the channel category is displayed:



When the artist name/song title is displayed:



- V
- The front panel display can indicate up to 14 alphanumeric characters at once. If the information contains more than 14 characters, the information scrolls from right to left.
- If the information contains a character that cannot be recognized by the unit, the character will be displayed with an underbar "\_".


#### Note

If a status message or an error message appears in the display, see "Status and error messages" on page 49.


### XM Satellite Radio search modes

You can search for the channel you want to listen to using one of three search modes. You can also enter the number directly to select the desired channel. (For details, see "Direct Number Access mode" on page 46.)


#### All Channel Search mode




- 1 Carry out "Selecting the XM Satellite Radio mode" on page 43.
- Press SEARCH MODE (or SRCH MODE on the remote control) repeatedly to select "ALL CH SEARCH".



3 To change the channel category, press CATEGORY (or A-E/CAT. j / i on the remote control) repeatedly.




To search a channel within all channels, press PRESET/TUNING/CH  $\ \ / \ \$  (or PRESET/CH  $\ \ \ / \ \ \$  on the remote control) repeatedly.




You can search a channel with the quick search by pressing and holding PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control).


#### Category Search mode




- 1 Carry out "Selecting the XM Satellite Radio mode" on page 43.
- 2 Press SEARCH MODE (or SRCH MODE on the remote control) repeatedly to select "CAT SEARCH".



3 To change the channel category, press CATEGORY (or A-E/CAT. j / i on the remote control) repeatedly.




To search a channel within the selected channel category, press PRESET/TUNING/CH  $\mid$  /  $\mid$  (or PRESET/CH  $\mid$  /  $\mid$  on the remote control) repeatedly.




You can search a channel with the quick search by pressing and holding PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control).

#### ■ Preset Search mode


Prior to selecting a preset channel in the Preset Search mode, you should preset XM Satellite Radio channels. For details, see "Setting XM Satellite Radio preset channels" on page 47. All preset channels (A1 to E8) recalls "001 Preview" by the factory setting.




- 1 Carry out "Selecting the XM Satellite Radio mode" on page 43.
- 2 Press SEARCH MODE (or SRCH MODE on the remote control) repeatedly to select "PRESET SEARCH".



To change the preset group (A to E), press CATEGORY (or A-E/CAT. j / i on the remote control) repeatedly.




To change the preset number (1 to 8), press PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control) repeatedly.




You can also select the preset number directly by pressing the numeric buttons (1 to 8) on the remote control.

■ Direct Number Access mode



- 1 Carry out "Selecting the XM Satellite Radio mode" on page 43.
- 2 Press SEARCH MODE (or SRCH MODE on the remote control) repeatedly to select "ALL CH SEARCH" or "CAT SEARCH".




3 Press the numeric buttons to enter the desired channel number.

For example, to enter the number 123, press the numeric buttons as shown below.



The display changes as follows.



If you enter fewer than three numbers, you may press ENT. to tune to the channel immediately or wait a few seconds to confirm the entered channel number.




V

- If no button is pressed within a few seconds after entering onedigit or two-digit number, the unit automatically confirms the entered channel number.
- Pressing a button other than numeric buttons or ENT. cancels the direct number access procedure.

# Setting XM Satellite Radio preset channels

You can use this feature to store up to 40 XM Satellite Radio channels (eight preset numbers in five preset groups, A1 to E8). You can then recall any preset channel easily by selecting the preset group and number as described in "Preset Search mode" on page 45.



1 Search the XM Satellite Radio channel you want to set as a preset channel.


To search the desired channel, carry out "All Channel Search mode" or "Category Search mode" on page 45, or "Direct Number Access mode" on page 46.



When the channel number "040" is selected


Press MEMORY on the unit (or remote control during the TUNER mode).

The MEMORY indicator flashes for about five seconds.




While the MEMORY indicator is flashing, press CATEGORY (or A-E/CAT. j / i on the remote control) to select a preset group (A to E).

The group letter appears.




While the MEMORY indicator is flashing, press PRESET/TUNING/CH | / h (or PRESET/CH u / d on the remote control) to select a preset number (1 to 8).



While the MEMORY indicator is flashing, press MEMORY on the unit (or the remote control) to preset the selected XM Satellite Radio channel.

A colon appears next to the preset number for confirmation, and the MEMORY indicator turns off.



#### Note

Presetting a new channel clears the former preset channel stored in the same preset group and number.

### ■ Status and error messages


If an operation takes longer than usual or an error occurs, one of the following messages may appear in the front panel display. In this case, read the cause and follow the corresponding remedies.


Message	Cause	Remedy	
CHECK ANTENNA	The XM Connect and Play digital antenna is not connected, or does not work properly.	Check the XM Connect and Play digital antenna connections.	
UPDATI NG	The XM user encryption code is being updated.	Wait until the encryption code is updated.	
NO SI GNAL	The signal is too weak.	Check the XM Connect and Play digital antenna connections and orient it for the best reception.	
LOADI NG	It takes longer than four seconds for audio or text data to be decoded.	Wait until the decoding process has finished.	
OFF AIR	The XM Satellite Radio channel you selected is not currently broadcasting any signal.	Check the channel number again or select another XM Satellite Radio channel.	
<xm></xm>	The channel Station ID (SID) is no longer available.		
/	No artist name/feature or song/program title is available.		
<cat></cat>	No channels are available for the selected category.	Select another channel category by pressing CATEGORY (or A-E/CAT. j / i on the remote control) repeatedly.	

### RECORDING


Recording adjustments and other operations are performed from the recording components. Refer to the operating instructions for those components.

(U.S.A. model)





- 1 Turn on the power of this unit and all connected components.
- 2 Select the source component you want to record from.



- Start playback (or select a broadcast station) on the source component.
- 4 Start recording on the recording component.

V

Do a test recording before you start an actual recording.

#### Notes

- When this unit is set in the standby mode, you cannot record between other components connected to this unit.
- The setting of TONE CONTROL, VOLUME, "SP LEVEL" (page 59) and the sound field programs does not affect recorded material.
- A source connected to the MULTI CH INPUT jacks of this unit cannot be recorded.
- S-video and composite video signals pass independently
  through this unit's video circuits. Therefore, when recording or
  dubbing video signals, if your video source component is
  connected to provide only an S-video (or only a composite
  video) signal, you can record only an S-video (or only a
  composite video) signal to your VCR.
- Digital signals input to the DIGITAL INPUT jacks are not output to the analog AUDIO OUT (L/R) jacks for recording. Likewise, analog signals input to the AUDIO IN (L/R) jacks are not output to the DIGITAL OUTPUT jack. Therefore, if your source component is connected to provide only digital (or analog) signals, you can only record digital (or analog) signals.
- A given input source is not output on the same REC OUT channel. (For example, the signal input from VCR IN is not output on VCR OUT.)
- Check the copyright laws in your country to record from records, CDs, radio, etc. Recording of copyrighted material may infringe copyright laws.

If you playback a video source that uses scrambled or encoded signals to prevent it from being dubbed, the picture itself may be disturbed due to those signals.

#### Special considerations when recording DTS software

The DTS signal is a digital bitstream. Attempting to digitally record the DTS bitstream will result in noise being recorded. Therefore, if you want to use this unit to record sources that have DTS signals recorded on them, the following considerations and adjustments need to be made.

For DVDs and CDs encoded with DTS, when your player is compatible with the DTS format, follow its operating instructions to make a setting so that the analog signal will be output from the player.

### **SOUND FIELD PROGRAM DESCRIPTIONS**

This unit is equipped with a variety of precise digital decoders that allow you to enjoy multi-channel playback from almost any sound source (stereo or multi-channel). This unit is also equipped with a YAMAHA digital sound field processing (DSP) chip containing several sound field programs which you can use to enhance your playback experience. Most of these sound field programs are precise digital recreations of actual acoustic environments found in famous concert halls, music venues, and movie theaters.

Y
The YAMAHA CINEMA DSP modes are compatible with all Dolby Digital, DTS, and Dolby Surround sources. Set the input mode to AUTO (see page 32) to enable this unit to automatically switch to the appropriate digital decoder according to the input signal.

#### Notes

- · This unit's DSP sound field programs are recreations of real-world acoustic environments made from precise measurements taken in the actual hall, etc. Thus you may notice variations in the strength of the reflections coming from the front, back, left and right.
- · Feel free to choose a sound field program based on your listening preference, and not purely on the name of the program itself.

### For movie/video sources

You can select from the following sound fields when playing movie or video sources. The sound fields marked "MULTI" can be used with multi-channel sources, like DVD, digital TV, etc. Those marked "2-CH" can be used with 2-channel (stereo) sources like TV programs, video tapes, etc.

Program selection methods vary depending on sound field program types. For details on how to select sound field programs, see "Selecting sound field programs" on pages 28 to 33.

Remote control button	Program	Features	Sources
1	STEREO: 2ch Stereo		
2	MUSI C: Pop/Rock	This program lends an enthusiastic atmosphere to the sound, giving you the feeling you are at an actual jazz or rock concert.	
	ENTERTAL NMENT: TV Sports Though the presence sound field is relatively narrow, the surround sound field employs the sound environment of a large concert hall. This effect enhances the experience of watching various TV programs such as news, variety shows, music programs or sports programs.		
3	ENTERTAL NMENT:  Mono Movi e  This program is provided for reproducing monaural video sources (such as movies). The program produces the optimum reverberation to create sound depth using only the presence sound field.		
	ENTERTAL NMENT: This program adds a deep and spatial feeling to video game sounds.  Game		MULTI 2-CH
	MOVIE THEATER: Spectacle	CINEMA DSP processing. This program creates the extremely wide sound field of a 70-mm movie theater. It precisely reproduces the source sound in detail, making both the video and the sound field incredibly real. This is ideal for any kind of video source encoded with Dolby Surround, Dolby Digital or DTS (especially large-scale movie productions).	2 611
4	MOVIE THEATER: Sci-Fi	CINEMA DSP processing. This program clearly reproduces dialog and sound effects in the latest sound form for science fiction films, thus creating a broad and expansive cinematic space amid silence. You can enjoy science fiction films in a virtual-space sound field that includes Dolby Surround, Dolby Digital and DTS-encoded software employing the most advanced techniques.	
	MOVIE THEATER: Adventure	CINEMA DSP processing. This program is ideal for precisely reproducing the sound design of the newest 70-mm and multi-channel soundtrack films. The sound field is made to be similar to that of the newest movie theaters, so the reverberations of the sound field itself are restrained as much as possible.	

#### SOUND FIELD PROGRAM DESCRIPTIONS

Remote control button	control Program Features		Sources
4	MOVIE THEATER: General	CINEMA DSP processing. This program is for reproducing sounds from 70-mm and multi-channel soundtrack films, and is characterized by soft and extensive sound field.	MULTI 2-CH
5	SUR. STANDARD	Standard processing for the selected decoder.	MULTI
3	SUR. ENHANCED	Enhanced processing for the selected decoder.	

# For music sources

You can select from the following sound fields when playing music sources, like CD, FM/AM broadcasting, tapes, etc.

Program selection methods vary depending on sound field program types. For details on how to select sound field programs, see "Selecting sound field programs" on pages 28 to 33.


Remote control button	Program	Features	
1	STEREO: 2ch Stereo	2-channel (left and right) playback.	
1	STEREO: 6ch Stereo		
	MUSIC: Hall in Vienna	HiFi DSP processing. A classic shoe-box type concert hall with approximately 1700 seats. Pillars and ornate carvings create extremely complex reflections which produce a very full, rich sound.	
2	MUSIC: The Bttm Line	HiFi DSP processing. This is the sound field at stage front in "The Bottom Line", a famous New York jazz club. The floor can seat 300 people to the left and right in a sound field offering a real and vibrant sound.	MULTI
	MUSIC: The Roxy Thtr	HiFi DSP processing. The ideal program for lively, dynamic rock music. The data for this program was recorded at LA's "hottest" rock club. The listener's virtual seat is at the center-left of the hall.	2-СН
3	ENTERTAL NMENT: Di sco	HiFi DSP processing. This program recreates the acoustic environment of a lively disco in the heart of a big city. The sound is dense and highly concentrated. It is also characterized by high-energy, "immediate" sound.	
5	SUR. STANDARD Standard processing for the selected decoder.		MULTI
3	SUR. ENHANCED	Enhanced processing for the selected decoder.	2-CH

# **ADVANCED OPERATIONS**

# Using the sleep timer

Use this feature to automatically set this unit in the standby mode after a certain amount of time. The sleep timer is useful when you are going to sleep while this unit is playing or recording a source. The sleep timer also automatically turns off any external components connected to AC OUTLET(S).

#### ■ Setting the sleep timer



Select a source and start playback on the source component.

# 2 Press SLEEP repeatedly to set the amount of time.



Each time you press SLEEP, the front panel display changes as shown below. The SLEEP indicator flashes while switching the amount of time for the sleep timer.



The SLEEP indicator lights up in the front panel display, and the display returns to the selected sound field program.

#### SLEEP indicator



#### ■ Canceling the sleep timer

Press SLEEP repeatedly until "SLEEP OFF" appears in the front panel display.


After a few seconds, "SLEEP OFF" disappears, and the SLEEP indicator goes off.



Y
The sleep timer setting can also be canceled by pressing
STANDBY on the remote control (or STANDBY/ON on the front
panel) to set this unit to the standby mode.

# Manually adjusting speaker levels

You can adjust the output level of each speaker while listening to a music source. This is also possible when playing sources through the MULTI CH INPUT jacks. Please note that this operation will override the level adjustments made in "BASIC SETUP" (page 23) and "SP LEVEL" (page 59).



#### 1 Press AMP.

# Press LEVEL repeatedly to select the speaker you want to adjust.

FRONT L Front left speaker level
CENTER Center speaker level
FRONT R Front right speaker level
SUR. R Surround right speaker level
SUR. B Surround back speaker level
SUR. L Surround left speaker level
SWFR Subwoofer level

У

Once you press LEVEL, you can also select the speaker by pressing  $U \ / \ O$ .

- **3** Press j / i to adjust the speaker output level. The control range is from +10 dB to -10 dB.
- 4 Press ENTER when you have completed your adjustment.

y
This operation can also be performed using the controls on the
front panel. Press NEXT repeatedly to select the speaker you
want to adjust, then press LEVEL -/+ to adjust the output level.

# **SET MENU**

You can use the following parameters in SET MENU to adjust a variety of system settings and customize the way this unit operates. Change the initial settings (indicated in bold under each parameter) to reflect the needs of your listening environment.

#### BASIC SETUP

Use to quickly setup basic system parameters (see page 23).

#### ■ MANUAL SETUP

Use to adjust speaker and system settings manually.

#### 1 SOUND MENU

Use to manually adjust any speaker setting, alter the quality and tone of the sound output by the system or compensate for video signal processing delays when using LCD monitors or projectors.

y Most of the parameters described in SOUND MENU are set automatically when you perform "BASIC SETUP" (see page 23). You can use SOUND MENU to make further adjustments.

Item	Item Features	
A) SPEAKER SET	Selects the size of each speaker, the speakers for low-frequency signal output, and the cross over frequency.	58
B) SP LEVEL	Adjusts the output level of each speaker.	59
C) SP DI STANCE	Adjusts the delay time of each speaker.	59
D)CENTER GEQ	Adjusts the tonal quality of the center speaker.	59
E) LFE LEVEL	Adjusts the output level of the LFE channel for Dolby Digital or DTS signals.	59
F) D. RANGE	Adjusts the dynamic range for Dolby Digital or DTS signals.	60
G) AUDI O SET	Customizes the muting level and audio delay.	60

#### **2 INPUT MENU**

Use to reassign digital input/outputs and select the input mode.

Item	Features	Page
A)I/O ASSIGN	Assigns jacks according to the component to be used.	60
B) I NPUT MODE	Selects the initial input mode of the source.	61
C) I NPUT RENAME	Changes the name of the inputs.	61


#### **3 OPTION MENU**

Use to adjust the optional system parameters.

Item	Features	
A) DI SPLAY SET	) DI SPLAY SET Adjusts the brightness of the display and converts video signals (HTR-5850 only).	
B) MEMORY GUARD	B) MEMORY GUARD Locks sound field program parameters and other SET MENU settings.	
C) PARAM. INI	Initializes the parameters of a group of sound field programs.	61
D) MULTI ZONE	Specifies the location of the speakers connected to the SPEAKERS B terminals.	62
E)XM RADIO SET	Displays the current reception level for the XM Connect and Play digital antenna.	62

# **Using SET MENU**

Use the remote control to access and adjust each parameter.



y You can change SET MENU parameters while the unit is reproducing sound.

#### Note

You cannot change some SET MENU parameters while the unit is in either cinema or music night listening mode.

- 1 Press AMP.
- 2 Press SET MENU.

"BASIC SETUP" appears in the front panel display.


3 Press  $\mbox{\it u}$  /  $\mbox{\it d}$  to display MANUAL SETUP.

MANUAL SETUP

4 Press ENTER to enter MANUAL SETUP.

1 SOUND MENU appears in the front panel display.

- 1 SOUND MENU
- 5 Press u / d to display the desired menu.



#### 6 Press ENTER to enter the displayed menu.

Repeat steps 5 and 6 to navigate to and enter the items you want to adjust.

To return to the previous menu level, press RETURN.

7 Press u / d to select the item you want to adjust, then press j / i to change the setting of the item.

Repeat this operation to select and adjust each setting. To return to the previous menu level, press RETURN.

8 To exit, press SET MENU when finished.

#### Memory back-up

The memory back-up circuit prevents the stored data from being lost even if this unit is in the standby mode. However, if the power cord is disconnected from the AC outlet, or the power supply is cut for more than one week, the stored data will be lost. If so, adjust the items again.

### 1 SOUND MENU

Use to manually adjust any speaker setting or compensate for video signal processing delays when using LCD monitors or projectors. Most of the SOUND MENU parameters are set automatically when you perform "BASIC SETUP" (see page 23).

#### ■ Speaker settings A) SPEAKER SET

Use to manually adjust any speaker setting.

У

If you are not satisfied with the bass sounds from your speakers, you can change these settings according to your preference.

# Front speakers FRONT Choices: LARGE, SMALL

- Select LARGE if you have large front speakers. The unit directs the entire range of the front left and right channel signals to the front left and right speakers.
- Select SMALL if you have small front speakers. The unit directs the low-frequency signals of the front channel to the speakers selected with "BASS OUT".

#### Center speaker CENTER

Choices: LRG, SML, NONE

- Select LRG if you have a large center speaker. The unit directs the entire range of the center channel signal to the center speaker.
- Select SML if you have a small center speaker. The unit directs the low-frequency signals of the center channel to the speakers selected with "BASS OUT".
- Select NONE if you do not have a center speaker. The unit directs all of the center channel signal to the front left and right speakers.

# **Surround left/right speakers** SUR. LR Choices: LRG, **SML**, NONE

- Select LRG if you have large surround left and right speakers. The entire range of the surround channel signal is directed to the surround left and right speakers.
- Select SML if you have small surround left and right speakers. The low-frequency signals of the surround channel are directed to the speakers selected with "BASS OUT".
- Select NONE if you do not have surround speakers.
   This will set the unit to the Virtual CINEMA DSP mode (see page 32) and automatically set the surround back speaker setting (SUR. B) to NONE.

#### Surround back speakerSUR. B

Choices: LRG, SML, NONE

- · Select LRG if you have a large surround back speaker.
- Select SML if you have a small surround back speaker.
  The low-frequency signals of the surround back
  channel are directed to the speakers selected with
  "BASS OUT", and the rest of the frequency signals are
  directed to the surround back speaker.
- Select NONE if you do not have a surround back speaker. The unit directs all of the surround back channel signal to the surround left and right speakers.

#### Bass out BASS OUT

Low-frequency (bass) signals can be directed to the subwoofer and/or the front left and right speakers according to the characteristics of your system. This setting also determines the routing of the LFE (low-frequency effect) signals found in Dolby Digital or DTS sources.

Choices: SWFR (subwoofer), FRONT, BOTH

- Select SWFR if you connect a subwoofer. LFE and low-frequency signals from other channels are directed to the subwoofer according to the speaker settings.
- Select FRONT if you do not use a subwoofer. LFE and low-frequency signals from other channels are directed to the front speakers according to the speaker settings (even if you have previously set the front speakers to SML).
- Select BOTH if you connect a subwoofer and you want to output low-frequency signals from front channels to both the front speakers and subwoofer. LFE and lowfrequency signals from other channels are also directed to the subwoofer according to the speaker settings. Use this function to reinforce low-frequency signals using the subwoofer when playing back sources such as CDs.

#### Cross over CrossOver

Use this feature to select a cross-over (cut-off) frequency for all low-frequency signals. All frequencies below the selected frequency will be sent to the subwoofer. Choices: 40Hz, 60Hz, 80Hz, 90Hz, 100Hz, 110Hz, 120Hz, 160Hz, 200Hz

#### Subwoofer phase SWFR PHASE

If bass sounds are lacking or unclear, use this feature to switch the phase of your subwoofer.

Choices: NRM (normal), REV (reverse)

- Select NRM if you do not want to reverse the phase of your subwoofer.
- Select REV to reverse the phase of your subwoofer.

#### ■ Speaker level B)SP LEVEL

Use these settings to manually balance the level of each speaker selected in SPEAKER SET (page 58).

Choices: -10.0 dB to +10.0 dB

- **FL** adjusts the balance of the front left speaker.
- **FR** adjusts the balance of the front right speaker.
- C adjusts the balance of the center speaker.
- **SL** adjusts the balance of the surround left speaker.
- **SR** adjusts the balance of the surround right speaker.
- **SB** adjusts the balance of the surround back speaker.
- **SWFR** adjusts the balance of the subwoofer.

#### ■ Speaker distance C)SP DISTANCE

Use this feature to manually input the distance of each speaker and adjust the delay applied to respective channel. Ideally, each speaker should be the same distance from the main listening position. However, this is not possible in most home situations. Thus, a certain amount of delay must be applied to the sound from each speaker so that all sound will arrive at the listening position at the same time.

#### Unit UNIT

Choices: meters (m), feet (ft)

Initial setting:

U.S.A. and Canada models: feet (ft)

Other models: meters (m)

- Select meters to input speaker distances in meters.
- Select feet to input speaker distances in feet.

#### Speaker distances

Choices: 0.3 to 24.0 m (1 to 80 ft)

- FRONT L adjusts the distance of the front left speaker.
   Initial setting: 3.0 m (10.0 ft)
- **FRONT R** adjusts the distance of the front right speaker. Initial setting: 3.0 m (10.0 ft)
- CENTER adjusts the distance of the center speaker.
   Initial setting: 3.0 m (10.0 ft)
- **SUR.L** adjusts the distance of the surround left speaker. Initial setting: 3.0 m (10.0 ft)
- **SUR.R** adjusts the distance of the surround right speaker. Initial setting: 3.0 m (10.0 ft)
- **SUR.B** adjusts the distance of the surround back speaker. Initial setting: 2.10 m (7.0 ft)
- SWFR adjusts the distance of the subwoofer. Initial setting: 3.0 m (10.0 ft)

#### ■ Center graphic equalizer D) CENTER GEQ

Use this feature to adjust the built-in 5-band graphic equalizer for the center channel so that the tonal quality of the center speaker matches that of the front speakers. You can make adjustments listening to the currently selected source component or a test tone.

You can adjust 5 frequency bands:

100Hz, 300Hz, 1kHz, 3kHz, 10kHz

Choices: -6 to +6 dB Initial setting: 0 dB

- Select ON to output test tones from the front left and center speakers, and adjust the tonal quality of the center speaker.
- Select OFF to stop the test tone and output the currently selected source component.

#### ■ Low-frequency effect level E) LFE LEVEL

Use to adjust the output level of the LFE (low-frequency effect) channel according to the capacity of your subwoofer or headphones. The LFE channel carries low-frequency special effects which are only added to certain scenes. This setting is effective only when this unit decodes Dolby Digital or DTS signals.

Choices: -20 to 0 dB

Speaker SP LFE

Select to adjust the speaker LFE level.

Headphone HP LFE

Select to adjust the headphone LFE level.

#### Note

Depending on the "LFE LEVEL" setting, some signals may not be output from the SUBWOOFER OUTPUT jack.

#### ■ **Dynamic range** F) D. RANGE

Use to select the amount of dynamic range compression to be applied to your speakers or headphones. This setting is effective only when the unit is decoding Dolby Digital and DTS signals.

Choices: MIN (minimum), STD (standard), MAX (maximum)

#### Speaker SP D. R

Select to adjust the speaker compression.

#### Headphone HP D. R

Select to adjust the headphone compression.

- Select MIN for listening to sources at low volume levels
- · Select STD for general use.
- · Select MAX for feature films.

#### ■ Audio settings G) AUDI O SET

Use to customize this units overall audio settings.

#### Muting type MUTE TYP.

Use to adjust how much the mute function reduces the output volume.

Choices: FULL, -20dB

- Select FULL to completely halt all output of sound.
- Select –20dB to reduce the current volume by 20 dB.

#### Audio delay A. DELAY

Use to delay the sound output and synchronize it with the video image. This may be necessary when using certain LCD monitors or projectors.

Choices: 0 to 160 ms

#### Tone bypass TC. BYPASS

Use to select whether audio output bypasses tone control circuitry when TREBLE and BASS (page 27) are set to 0 dB.

Choices: AUTO, OFF

- Select AUTO if you want signals to bypass tone control circuitry to provide the purest signal possible.
- Select OFF if you do not want signals to bypass tone control circuitry.

### 2 INPUT MENU

Use to reassign digital input/outputs and select the input mode.

#### ■ Input/output assignment

A)I/O ASSIGN

You can assign jacks according to the component to be used if this unit's initial settings do not correspond to your needs. Change the following parameters to reassign the respective jacks and effectively connect more components.

Once the inputs have been reassigned, you can select the corresponding component by using INPUT on the front panel or the input selector buttons on the remote control.

# For COMPONENT VIDEO jacks A (C. V[A]) and B (C. V[B])

Choices: [A] **DVD**, DTV/CBL, V-AUX, VCR [B] DVD, **DTV/CBL**, V-AUX, VCR

#### [HTR-5850]

#### For OPTICAL OUTPUT jack 1 (OUT(1))

Choices: MD/CD-R, CD, V-AUX, DTV/CBL, VCR, DVD

#### For OPTICAL INPUT jacks 2 (IN (2)),

3 (IN (3)) and 4 (IN (4))

Choices: (2) CD, MD/CD-R, DVD, DTV/CBL, V-AUX, VCR

(3) CD, MD/CD-R, **DVD**, DTV/CBL, V-AUX, VCR

(4) CD, MD/CD-R, DVD, **DTV/CBL**, V-AUX, VCR

#### For COAXIAL INPUT jack 5 (IN (5))

Choices:  $\mbox{CD}$ , MD/CD-R, DVD, DTV/CBL, V-AUX, VCR

#### [HTR-5840]

### For OPTICAL INPUT jacks 1 (I $\mathbb{N}$ (3)),

**2(IN(4))** 

Choices: (1) CD, MD/CD-R, **DVD**, DTV/CBL, V-AUX, VCR

(2) CD, MD/CD-R, DVD, **DTV/CBL**, V-AUX, VCR

#### For COAXIAL INPUT jack 3 (IN (5))

Choices: **CD**, MD/CD-R, DVD, DTV/CBL, V-AUX, VCR

#### Notes

- You cannot select a specific item more than once for the same type of jack.
- When you connect a component to both the COAXIAL and OPTICAL jacks, priority is given to the input signals from the COAXIAL jack.

#### ■ Input mode B) I NPUT MODE

Use this feature to designate the input mode for sources connected to the DIGITAL INPUT jacks when you turn on this unit (see page 32 for details about the input mode). Choices: **AUTO**. LAST

- Select AUTO to allow this unit to automatically detect the type of input signal and select the appropriate input mode.
- Select LAST to set this unit to automatically select the last input mode used for that source.

#### Note

Even if LAST is selected, the last setting for the EXTD SUR. button will not be recalled.

#### ■ Input rename C) I NPUT RENAME

Use this feature to change the name of the inputs in the front panel display.

- 1 Press an input selector button to select the input you want to change the name of.
- 2 Press AMP.
- 3 Press j / i to place the \_ (under-bar) under the space or the character you want to edit.
- 4 Press u / d to select the character you want, then use j / i to move to the next space.
  - You can use up to 8 characters for each input.
  - Press Cd to change the character in the following order, or press U to go in the reverse order:
     A to Z, a space, 0 to 9, a space, a to z, a space, symbols (#, \*, -, +, etc.)
- 5 Repeat steps 1 through 4 to rename each input.
- **6** To exit, press SET MENU when finished.

### 3 OPTION MENU

Use to adjust the optional system parameters.

#### ■ **Display settings** A) DI SPLAY SET

**Dimmer** DI MMER

Use to adjust the brightness of the front panel display. Choices: –4 to **0** 

#### <HTR-5850 only>

#### Video conversion V CONV.

Use this feature to turn on/off conversion of composite (VIDEO) signals to S-video signals. This allows you to output converted video signals from the S VIDEO jacks when no S-video signals are input.

Choices: ON, OFF

- Select OFF not to convert any signals (except S-video signals to composite signals).
- Select ON to convert composite signals to S-video signals and component signals, and to convert S-video signals to component signals.
- Regardless of the setting, S-video signals are always converted to composite signals.

#### Note

Converted video signals are only output to the MONITOR OUT jacks. When recording you must make the same type of video connections (i.e., S-video) between each component.

#### ■ Memory guard B) MEMORY GUARD

Use this feature to prevent accidental changes to DSP program parameter values and other system settings.

Choices: ON, OFF

Select ON to protect:

- DSP program parameters
- All SET MENU items
- · All speaker levels

#### Note

When MEMORY GUARD is set to ON, you cannot select any other SET MENU items.

#### ■ Parameter initialization C) PARAM. INI

Use this feature to initialize the parameters for each sound field program within a sound field program group. When you initialize a sound field program group, all of the parameter values within that group revert to their initial settings. Press the corresponding numeric button for the sound field program that you want to initialize.

Choices: STEREO, MUSIC, ENTERTAINMENT, MOVIE, STANDARD

#### **Notes**

- You cannot automatically revert to the previous parameter settings once you initialize a sound field program group.
- You cannot separately initialize individual sound field programs.
- You cannot initialize any program groups when "MEMORY GUARD" is set to ON.

#### ■ Zone set D)MULTI ZONE

Use to specify the location of speakers connected to the SPEAKERS B terminals.

#### Speaker B setting SP B

Use this feature to select the location of the front speakers connected to the SPEAKERS B terminals.

Choices: FRONT, ZONE B

- Select FRONT to turn on/off SPEAKERS A and B
  when the speakers connected to the SPEAKERS B
  terminals are set in the main room.
- Select ZONE B if the speakers connected to the SPEAKERS B terminals are set in another room. If SPEAKERS A is turned OFF and SPEAKERS B is turned ON, all the speakers including the subwoofer in the main room are muted and the unit outputs sound from SPEAKERS B only.

#### Notes

- If you connect headphones to the PHONES jack on the unit when "SP B" is set to ZONE B, the sound is output from both headphones and SPEAKERS B.
- If a DSP program is selected when "SP B" is set to ZONE B, the unit automatically enters the Virtual CINEMA DSP mode.

#### ■ XM Radio setting E) XM RADIO SET

#### XM Radio antenna XM ANT.

Use to check the current reception level for the XM Connect and Play digital antenna connected to this unit. For the best reception, orient the XM Connect and Play digital antenna so that a value of XX% or more is displayed here.

Range: NONE, 0 to 100%

#### Note

"NONE" is displayed if the XM Connect and Play digital antenna is not connected to this unit. If this happens, check the antenna connections (see page 40).

# ADVANCED

# **ADVANCED SETUP MENU**


The ADVANCED SETUP menu is displayed in the front panel display.

У

- During the advanced setup procedure, audio output is muted.
- During the advanced setup procedure, only the STANDBY/ON, STRAIGHT (EFFECT) and PROGRAM | / h buttons on the front panel are available for operation.

#### **CAUTION**

Be sure to set the speaker impedance before using this unit to play back audio or video signals.



1 Turn off the power to this unit, and while holding down STRAIGHT (EFFECT), press STANDBY/ON.

This unit turns on, and the ADVANCED SETUP menu appears in the front panel display.



While holding down, press



2 Press PROGRAM | / h repeatedly to move through the menu and select the item you want to set up.

See the end of this section for a complete list of available parameters.



3 Press STRAIGHT (EFFECT) repeatedly to toggle between the available parameters.



4 Press STANDBY/ON to confirm your selection.



This completes the advanced setup procedure. The settings you made are reflected the next time this unit's power is turned on.

#### ■ ADVANCED SETUP menu items

Change the initial settings (indicated in bold under each parameter) to reflect the needs of your listening environment.

#### Speaker impedance SP I MP.

Use to switch the speaker impedance for this unit. Choices: **8**  $\Omega$  MIN, 4  $\Omega$  MIN

- Select 8  $\Omega$  MIN to set the speaker impedance to 8  $\Omega$ .
- Select 4  $\Omega$  MIN to set the speaker impedance to 4  $\Omega$ .

SP IMP.	Speaker	Impedance level	
	Front	If you use one set (A or B), the impedance of each speaker must be 4 $\Omega$ or higher.	
4ΩMIN	FIOIL	If you use two sets (A and B), the impedance of each speaker must be $8\Omega$ or higher.	
	Center	The impedance of each	
	Surround	speaker must be 6 $\Omega$ or	
	Surround back	higher.	
	Front	If you use one set (A or B), the impedance of each speaker must be 8 $\Omega$ or higher.	
8ΩMIN	Front	If you use two sets (A and B), the impedance of each speaker must be $16~\Omega$ or higher.*	
	Center	The impedance of each	
	Surround	speaker must be $8  \Omega$ or	
	Surround back	higher.	

<sup>\*</sup> The Canada model cannot use two separate speakers system (A and B) simultaneously when SP IMP. is set to 8  $\Omega$  MIN.

#### Factory presets PRESET

Use to reset all parameters to the factory prestes (see page 77).

Choices: CANCEL, RESET

- Select CANCEL if you do not want this unit's parameters to be initialized when you reset the factory presets.
- Select RESET if you want all of this unit's parameters to be initialized when you reset the factory presets.

#### Note

This setting does not affect ADVANCED SETUP menu item parameters.

#### <Except for HTR-5840: U.K. and Europe models>

#### Remote REMOTE

Use to switch the ID for the remote control of this unit. Choices: **ID1**, ID2

- Select ID1 to operate this unit using the default code.
- Select ID2 to operate this unit using an alternative code.

#### Note

You must also make settings for the remote control (see page 68).


# REMOTE CONTROL FEATURES

In addition to controlling this unit, the remote control can also operate other A/V components made by YAMAHA and other manufacturers. To control other components, you must set up remote control with the appropriate remote control codes.

### Control area


#### ■ Controlling this unit

The shaded areas below can be used to control this unit when the AMP mode is selected. Press AMP to activate the AMP mode.



#### ■ Controlling other components

The shaded areas below can be used to control other components. Each button has a different function depending on the selected components. Select the component you want to control by pressing an input selector button.



### Setting remote control codes

You can control other components by setting the appropriate remote control codes. Codes can be set up for each input area. For a complete list of available remote control codes, refer to "LIST OF REMOTE CONTROL CODES" at the end of this manual.

The following table shows the default component (Library: component category) and the remote control code for each area.

#### **Remote Control Code Default Settings**


Input area	Library (component category)	Manufacturer	Default YAMAHA code
CD	CD	YAMAHA	0005
MD/CD-R	MD	YAMAHA	0024
TUNER	TUNER	ҮАМАНА	0023*1 0033*2
DVD	DVD	YAMAHA	0098
DTV/CBL	_	_	_
V-AUX	_	_	_
VCR	_	_	-
☆	DVR	YAMAHA	0208
☆☆	-	_	_

<sup>\*1</sup> U.K. and Europe models

#### Note

You may not be able to operate your YAMAHA component even if a YAMAHA remote control code is initially set as listed above. In this case, try to set other YAMAHA remote control code(s).

1 Press an input selector button or ☆/☆☆ to select the component you want to set up.



2 Press CODE SET using a ballpoint pen or similar object.

The TRANSMIT indicator on the remote control flashes twice.



3 Press the numeric buttons (0 to 9) to enter the four-digit remote control code for the component to be used.

Refer to "LIST OF REMOTE CONTROL CODES" at the end of this manual.



The TRANSMIT indicator on the remote control flashes twice, and the remote control code for the selected component is set.


#### Notes

- If the manufacturer of your component has more than one code, try each of them until you find the correct one.
- If you wait for more than 30 seconds during step 3, the setup process is canceled. If this happens, start over from step 2.

<sup>\*2</sup> Other models

# Controlling other components

Once you set the appropriate remote control codes, you can use this remote to control your other components. Note that some buttons may not correctly operate the selected component. Use the input selector buttons to select the component you want to operate. The remote control automatically switches to the appropriate control mode for that component.



\		DVD player	VCR	Digital TV/ Cable TV	CD player	MD/CD recorder	Tuner
1	AV POWER	Power *1	Power *1	VCR power *3	Power *1	Power *1	Power *1
2	TV POWER	TV power *2	TV power *2	TV power	TV power *2	TV power *2	TV power *2
3	TV CH+	TV channel up *2	TV channel up *2	TV channel up	TV channel up *2	TV channel up *2	TV channel up *2
	TV CH –	TV channel down *2	TV channel down *2	TV channel down	TV channel down *2	TV channel down *2	TV channel down *2
4	TV VOL +	TV volume up *2	TV volume up *2	TV volume up	TV volume up *2	TV volume up *2	TV volume up *2
	TV VOL -	TV volume down *2	TV volume down *2	TV volume down	TV volume down *2	TV volume down *2	TV volume down *2
5	TV MUTE	TV mute *2	TV mute *2	TV mute	TV mute *2	TV mute *2	TV mute *2
6	TV INPUT	TV input *2	TV input *2	TV input	TV input *2	TV input *2	TV input *2
7	1-9, 0, +10	Numeric buttons	Numeric buttons	Numeric buttons	Numeric buttons	Numeric buttons	Preset stations (1-8)
8	TITLE	Title					
9	PRESET/CH u	Up	VCR channel up				Preset up (1-8)
	PRESET/CH d	Down	VCR channel down				Preset down (1-8)
	j	Left					Preset down (A-E)
	i	Right					Preset up (A-E)
	ENTER	Play					
0	RETURN	Return					
Α	REC/ DISC SKIP	Disc skip (player)	Rec	VCR rec *3	Disc skip	Rec (MD)	
	р	Play	Play	VCR play *3	Play	Play	
	W	Search backward	Search backward	VCR search backward *3	Search backward	Search backward	
	f	Search forward	Search forward	VCR search forward *3	Search forward	Search forward	
	AUDIO	Audio					
	е	Pause	Pause	VCR pause *3	Pause	Pause	
	b	Skip backward			Skip backward	Skip backward	
	а	Skip forward			Skip forward	Skip forward	
	S	Stop	Stop	VCR stop *3	Stop	Stop	
В	ENT.	Title/Index	Enter	Enter	Index	Index	
С	MENU	Menu					
D	DISPLAY	Display		Display	Display	Display	

<sup>\*1</sup> This button functions only when the original remote control of the component has a POWER button.

<sup>\*2</sup> These buttons can operate your TV without switching the input if the remote control code is set in DTV/CBL or ☆☆.

When the remote control code for your TV is set up in both the DTV/CBL and ☆☆ areas, priority is given to the signal in the DTV/CBL area.

<sup>\*3</sup> These buttons can operate your VCR without switching the input to VCR if the remote control code is set in VCR.

# Switching library codes < Except for HTR-5840: U.K. and Europe models>

You can select the unit you want to operate with the remote control by entering the library code.

#### Press CODE SET using a ballpoint pen or similar object.

The TRANSMIT indicator on the remote control flashes twice.



#### Enter the code number "9991" or "9992" (see the table below).

The TRANSMIT indicator on the remote control flashes twice, and the library code is changed.

AMP library code (remote control setting)	Function	Remote control ID (unit setting: see page 64)
9991	To operate this unit using the default code.	ID1 (initial setting)
9992	To operate this unit using an alternative code.	ID2


When using multiple YAMAHA receivers/amplifiers, you may be able to operate the other components simultaneously with the default code setting. In this case, set one of the alternative codes to operate this unit separately.

#### Note

You must also make settings for the receiver/amplifier.

# Clearing set up remote control codes

Press an input selector button or ☆/☆☆ to select the component control for which you want to clear the remote control code.



#### Press CODE SET using a ballpoint pen or similar object.

The TRANSMIT indicator on the remote control flashes twice.



#### Enter the code number "0000".

The TRANSMIT indicator on the remote control flashes twice, and the remote control code for the selected component is cleared.

- y
   If you do not press any button within 30 seconds after step 2, the clearing process is canceled. If this happens, start over from
- You can clear all setup remote control codes at once by entering the code number "9990".

## **EDITING SOUND FIELD PARAMETERS**

### What is a sound field

What really creates the rich, full tones of a live instrument are the multiple reflections from the walls of the room. In addition to making the sound "live", these reflections enable us to tell where the player is situated, and the size and shape of the room in which we are sitting.

#### Elements of a sound field

In any environment, in addition to the direct sound coming straight to our ears from the player's instrument, there are two distinct types of sound reflections that combine to make up the sound field:

### Early reflections

Reflected sounds reach our ears extremely rapidly (50 ms – 100 ms after the direct sound), after reflecting from one surface only – for example, from the ceiling or a wall. Early reflections actually add clarity to the direct sound.

#### Reverberations


These are caused by reflections from more than one surface – walls, ceiling, the back of the room – so numerous that they merge together to form a continuous sonic "afterglow". They are non-directional, and lessen the clarity of the direct sound.


Direct sound, early reflections and subsequent reverberation taken together help us to determine the subjective size and shape of the room, and it is this information that the digital sound field processor reproduces in order to create sound fields.

If you could create the appropriate early reflections and subsequent reverberations in your listening room, you would be able to create your own listening environment. The acoustics in your room could be changed to those of a concert hall, a dance floor, or virtually any size room at all. This ability to create sound fields at will is exactly what YAMAHA has done with the digital sound field processor.

### Changing parameter settings

You can enjoy good quality sound with the factory preset parameters. Although you do not have to change the initial settings, you can change some of the parameters to better suit the input source or your listening room.







1 Press AMP.




Select the sound field program you want to adjust.



3 Press u / d to select the parameters.



4 Press j / i to change the parameter value.



If you press and hold j / i to change the parameter value, the front panel display automatically stops at the factory preset parameter momently.

## 5 Repeat steps 2 through 4 as necessary to change other program parameters.

### Note

You cannot change parameter values when "MEMORY GUARD" is set to ON. If you want to change the parameter values, set "MEMORY GUARD" to OFF (see page 61).

### Memory back-up

The memory back-up circuit prevents the stored data from being lost even if this unit is set in the standby mode, the power cord is disconnected from the AC outlet, or the power supply is temporarily cut due to power failure. However, if the power is cut for more than one week, the parameter values will return to the factory settings. If this happens, edit the parameter value again.

## Resetting parameters to the factory presets

Use PARAM. INI (see pages 61).

### **SOUND FIELD PARAMETER DESCRIPTIONS**

You can adjust the values of certain digital sound field parameters so the sound fields are recreated accurately in your listening room. Not all of the following parameters are found in every program.

### ■ DSP LEVEL (DSP level)

Function: Adjusts the level of all the DSP effect sounds within a narrow range.

Description: Depending on the acoustics of your listening room, you may want to increase or decrease the DSP

effect level relative to the level of the direct sound.

Control range: -6 dB to +3 dB

### ■ INIT.DLY (Initial delay)


Function: Changes the apparent distance from the source sound by adjusting the delay between the direct sound

and the first reflection heard by the listener.

Description: The smaller the value, the closer the sound source seems to the listener. The larger the value, the farther

it seems. For a small room, set to a small value. For a large room, set to a large value.

Control range: 1 to 99 msec



### For 2ch Stereo:

### **■** DIRECT (Direct)

Function: Bypasses this unit's decoders and DSP processors for pure high fidelity sound when playing 2-channel

analog sources. The AUTO setting is effective only when BASS and TREBLE are set to 0 dB.

Choices: AUTO, OFF

### Notes

• When multi-channel signals (Dolby Digital and DTS) are input, they are downmixed to 2 channels and output from the front left and right speakers.

When "BASS OUT" is set to BOTH, or "FRONT" set to SMALL and "BASS OUT" set to SWFR, front left and right speaker low-frequency signals are redirected to the subwoofer.

#### SOUND FIELD PARAMETER DESCRIPTIONS

#### For 6ch Stereo:

Function: These parameters adjust the volume level for each channel in 6-channel stereo mode.

Control range: 0 to 100%

■ CT LEVEL (Center level)

■ SL LEVEL (Surround left level)

SR LEVEL (Surround right level)

■ SB LEVEL (Surround back level)

### For PRO LOGIC IIx Music and PRO LOGIC II Music:

### **■** PANORAMA (Panorama)

Function: Sends stereo signals to the surround speakers as well as the front speakers for a wraparound effect.

Choices: **OFF**, ON

### **■** DIMENSION (Dimension)

Function: Gradually adjusts the sound field either towards the front or towards the rear. Control range: –3 (towards the rear) to +3 (towards the front), initial setting is STD (standard).

### ■ CT WIDTH (Center width)

Function: Adjusts the center image from all three front speakers to varying degrees. A larger value adjusts the

center image towards the front left and right speakers.

Control range: 0 (center channel sound is output only from center speaker) to 7 (center channel sound is output only

from front left and right speakers)

Initial setting: 3

#### Note

This parameter can be set only when SUR. STANDARD is selected.

### For DTS Neo:6 Music:

### **■** C. IMAGE (Center image)

Function: Adjusts the center image from all three front speakers to varying degrees.

Control range: 0 to 1.0 Initial setting: 0.3

### Note

This parameter can be set only when SUR. STANDARD is selected.

## **TROUBLESHOOTING**

Refer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, set this unit to the standby mode, disconnect the power cord, and contact the nearest authorized YAMAHA dealer or service center.

### ■ General

Problem	Cause	Remedy	Refer to page
This unit fails to turn on when STANDBY/ ON (or SYSTEM	The power cord is not connected or the plug is not completely inserted.	Connect the power cord firmly.	_
POWER) is pressed,	The impedance setting is incorrect.	Set the impedance to match your speakers.	64
or enters the standby mode soon after the power has been turned on.	The protection circuitry has been activated.	Make sure all speaker wire connections on this unit and on all speakers are secure and that the wire for each connection does not touch anything other than its respective connection.	11-13
	This unit has been exposed to a strong external electric shock (such as lightning or strong static electricity).	Set this unit in the standby mode, disconnect the power cord, plug it back in after 30 seconds, then use it normally.	_
No sound	Incorrect input or output cable connections.	Connect the cables properly. If the problem persists, the cables may be defective.	14-20
	The input mode is set to DTS or ANALOG.	Select AUTO.	32
	No appropriate input source has been selected.	Select an appropriate input source with INPUT, MULTI CH INPUT (or MULTI CH IN on the remote control) or the input selector buttons.	28
	Speaker connections are not secure.	Secure the connections.	12
	The front speakers to be used have not been selected properly.	Select the front speakers with SPEAKERS A and/or B.	26
	The volume is turned down.	Turn up the volume.	_
	The sound is muted.	Press MUTE or any operation button of this unit to resume audio output, then adjust the volume.	27
	The input mode is set to ANALOG while playing a source encoded with a DTS signal.	Set the input mode to AUTO or DTS.	32
	Signals this unit cannot reproduce are being received from a source component, such as a CD-ROM.	Play a source whose signals can be reproduced by this unit.	_
No picture	The output and input for the picture are connected to different types of video jacks.	Turn on the video conversion function.	61

Problem	Cause	Remedy	Refer to page
The sound suddenly	The protection circuitry has been activated	Check that the impedance selector setting is correct.	64
goes off.	because of a short circuit, etc.	Check that the speaker wires are not touching each other and then turn this unit back on.	_
	The sleep timer has turned the unit off.	Turn on the power, and play the source again.	_
	The sound is muted.	Press MUTE to cancel a mute.	27
Only the speaker on one side can be	Incorrect cable connections.	Connect the cables properly. If the problem persists, the cables may be defective.	12
heard.	Incorrect balance settings in SET MENU.	Adjust the SP LEVEL settings.	59
Only the center speaker outputs substantial sound.	When playing a monaural source with a CINEMA DSP program, the source signal is directed to the center channel, and the front and surround speakers output effect sounds.		
No sound from the	The sound field programs are turned off.	Press STRAIGHT (EFFECT) to turn them on.	32
effect speakers.	You are using a source or program combination that does not output sound from all channels.	Try another sound field program.	30, 51
No sound from the center speaker.	The output level of the center speaker is set to minimum.	Raise the level of the center speaker.	59
	"CENTER" in SET MENU is set to NONE.  Select the appropriate setting for the center spe		58
	One of the HiFi DSP programs (except for 6ch Stereo) has been selected.	Try another sound field program.	30, 51
No sound from the surround speakers.	The output level of the surround speakers is set to minimum.	Raise the output level of the surround speakers.	59
	"SUR. LR" in SET MENU is set to NONE.	Select the appropriate setting for the surround left and right speakers.	58
	A monaural source is being played with STRAIGHT.	Press STRAIGHT (EFFECT) to turn on the sound fields.	_
No sound from the surround back speaker.	"SUR. LR" in SET MENU is set to NONE.	If the surround left and right speakers are set to NONE, the surround back speaker setting is automatically set to NONE. Select the appropriate setting for the surround speakers.	58
	"SUR. B" in SET MENU is set to NONE.	Select LRG or SML.	58
No sound from the subwoofer.	"BASS OUT" in SET MENU is set to FRONT when a Dolby Digital or DTS signal is being played.	Select SWFR or BOTH.	58
	"BASS OUT" in SET MENU is set to SWFR or FRONT when a 2-channel source is being played.	Select BOTH.	58
	The source does not contain low bass signals.		

Problem	Cause	Remedy	Refer to page	
Dolby Digital or DTS sources cannot be played. (Dolby Digital	The connected component is not set to output Dolby Digital or DTS digital signals.	Make an appropriate setting following the operating instructions for your component.	_	
or DTS indicator in the front panel display does not light up.)	The input mode is set to ANALOG.	Set the input mode to AUTO or DTS.	32	
A "humming" sound can be heard.	Incorrect cable connections.	Firmly connect the audio plugs. If the problem persists, the cables may be defective.	_	
The volume level cannot be increased, or the sound is distorted.	The component connected to the OUT (REC) jacks of this unit is turned off.	Turn on the power to the component.	_	
The sound effect cannot be recorded.	It is not possible to record the sound effect with a recording component.			
A source cannot be recorded by a digital	The source component is not connected to this unit's DIGITAL INPUT jacks.	Connect the source component to the DIGITAL INPUT jacks.	14-19	
recording component connected to this DIGITAL OUTPUT jack.	Some components cannot record the Dolby Digital or DTS sources.			
A source cannot be recorded by an analog component connected to the AUDIO OUT jacks.	The source component is not connected to this unit's analog AUDIO IN jacks.	Connect the source component to the analog AUDIO IN jacks.	14-19	
The sound field parameters and some other settings on this unit cannot be changed.	"MEMORY GUARD" in SET MENU is set to ON.	MENU is Select OFF.		
This unit does not operate properly.	The internal microcomputer has been frozen by an external electric shock (such as lightning or excessive static electricity) or by a power supply with low voltage.	Disconnect the AC power cord from the outlet and then plug it in again after about 30 seconds.	_	
"CHECK SP WIRES" appears in the front panel display.	Speaker cables are short circuited.	Make sure all speaker cables are connected correctly.	12	
There is noise interference from digital or radio frequency equipment, or this unit.	This unit is too close to the digital or high-frequency equipment.	Move this unit further away from such equipment.	_	
The picture is disturbed.	The video source uses scrambled or encoded signals to prevent dubbing.			
This unit suddenly turns into the standby mode.	The internal temperature becomes too high and the overheat protection circuitry has been activated.	Wait about 1 hour for this unit to cool down and then turn it back on.	_	

### ■ Tuner

	Problem	Cause	Remedy	Refer to page
	FM stereo reception is noisy.	The characteristics of FM stereo broadcasts may cause this problem when the transmitter is too far away or	Check the antenna connections.  Try using a high-quality directional FM antenna.	20
		the antenna input is poor.	Use the manual tuning method.	35
FM	There is distortion, and clear reception cannot be obtained even with a good FM antenna.	There is multipath interference.	Adjust the antenna position to eliminate multipath interference.	_
	The desired station	The signal is too weak.	Use a high-quality directional FM antenna.	20
	cannot be tuned in with the automatic tuning method.		Use the manual tuning method.	35
	Previously preset stations can no longer be tuned in.	This unit has been disconnected for a long period.	Preset the stations again.	35
	The desired station cannot be tuned in with	The signal is weak or the antenna connections are loose.	Tighten the AM loop antenna connections and orient it for the best reception.	_
	the automatic tuning method.		Use the manual tuning method.	35
AM	There are continuous crackling and hissing noises.	Noises result from lightning, fluorescent lamps, motors, thermostats and other electrical equipment.	Use an outdoor antenna and a ground wire. This will help somewhat, but it is difficult to eliminate all noise.	_
	There are buzzing and whining noises.	A TV set is being used nearby.	Move this unit away from the TV.	_

### ■ Remote control


Problem	Cause	Remedy	Refer to page
The remote control does not work nor function properly.	Wrong distance or angle.	The remote control will function within a maximum range of 6 m (20 ft) and no more than 30 degrees offaxis from the front panel.	7
	Direct sunlight or lighting (from an inverter type of fluorescent lamp, etc.) is striking the remote control sensor of this unit.	Reposition this unit.	
	The batteries are weak.	Replace all batteries.	3
	The remote control code was not correctly set.  Set the remote control code correctly REMOTE CONTROL CODES" at t manual.		66
		Try to set another code for the same manufacturer using "LIST OF REMOTE CONTROL CODES" at the end of this manual.	66
	< Except for HTR-5840: U.K. and Europe models > The remote control ID and this unit's ID do not match.	Switch the library code.	68
	Even if the remote control code is correctly set, there are some models that do not respond to the remote control.		

## RESETTING THE FACTORY PRESETS

If you want to reset all of your unit's parameters for any reason, do the following. This procedure completely resets ALL parameters, including the SET MENU, level, assign and tuner presets.

Be sure this unit is in standby mode.

(U.S.A. model)



With the unit in standby mode, hold down STRAIGHT (EFFECT) on the front panel and press STANDBY/ON.

The ADVANCED SETUP menu appears in the front panel display.



While holding down, press



y
To cancel the initialization procedure without making any changes, press STANDBY/ON.

2 Press PROGRAM | / h repeatedly to move through the menu and select "PRESET".



3 Press STRAIGHT (EFFECT) to select the desired setting.



RESET To reset the unit to its factory presets.

CANCEL To cancel without making any changes.

4 Press STANDBY/ON to confirm your selection.



If you selected "RESET", the unit is reset to its factory presets and switches to standby mode. If you selected "CANCEL", the unit switches to standby mode and nothing is reset.

### **GLOSSARY**

### Audio formats

### ■ Dolby Digital

Dolby Digital is a digital surround sound system that gives you completely independent multi-channel audio. With 3 front channels (left, center, and right), and 2 surround stereo channels, Dolby Digital provides 5 full-range audio channels. With an additional channel especially for bass effects, called LFE (low frequency effect), the system has a total of 5.1-channels (LFE is counted as 0.1 channel). By using 2-channel stereo for the surround speakers, more accurate moving sound effects and surround sound environment are possible than with Dolby Surround. The wide dynamic range (from maximum to minimum volume) reproduced by the 5 full-range channels and the precise sound orientation generated using digital sound processing provide listeners with previously unheard of excitement and realism.

With this unit, any sound environment from monaural up to a 5.1-channel configuration can be freely selected for your enjoyment.

### ■ Dolby Digital EX

Dolby Digital EX creates 6 full-bandwidth output channels from 5.1-channel sources. This is done using a matrix decoder that derives 3 surround channels from the 2 in the original recording. For the best results, Dolby Digital EX should be used with movie sound tracks recorded with Dolby Digital Surround EX. With this additional channel, you can experience more dynamic and realistic moving sound especially with scenes with "flyover" and "fly-around" effects.

### ■ Dolby Pro Logic II

Dolby Pro Logic II is an improved technique used to decode vast numbers of existing Dolby Surround software. This new technology enables a discrete 5-channel playback with 2 front left and right channels, 1 center channel, and 2 surround left and right channels (instead of only 1 surround channel for conventional Pro Logic technology). Music and Game modes are also available for 2-channel sources in addition to the Movie mode.

### ■ Dolby Pro Logic IIx

Dolby Pro Logic IIx is a new technology enabling discrete multi-channel playback from 2-channel or multi-channel sources. There is a Music mode for music, a Movie mode for movies (for 2-channel sources only) and a Game mode for games.

### **■** Dolby Surround

Dolby Surround uses a 4 channel analog recording system to reproduce realistic and dynamic sound effects: 2 front left and right channels (stereo), a center channel for dialog (monaural), and a surround channel for special sound effects (monaural). The surround channel reproduces sound within a narrow frequency range.

Dolby Surround is widely used with nearly all video tapes and laser discs, and in many TV and cable broadcasts as well. The Dolby Pro Logic decoder built into this unit employs a digital signal processing system that automatically stabilizes the volume on each channel to enhance moving sound effects and directionality.

### ■ DTS 96/24

DTS 96/24 offers an unprecedented level of audio quality for multi-channel sound on DVD-Video, and is fully backward-compatible with all DTS decoders. "96" refers to a 96 kHz sampling rate (compared to the typical 48 kHz sampling rate). "24" refers to 24-bit word length. DTS 96/24 offers sound quality transparent to the original 96/24 master, and 96/24 5.1-channel sound with full-quality full-motion video for music programs and motion picture soundtracks on DVD-video.

### ■ DTS (Digital Theater Systems) Digital Surround

DTS digital surround was developed to replace the analog soundtracks of movies with a 6-channel digital sound track, and is now rapidly gaining popularity in movie theaters around the world. Digital Theater Systems Inc. has developed a home theater system so that you can enjoy the depth of sound and natural spatial representation of DTS digital surround in your home. This system produces practically distortion-free 6-channel sound (technically, a left, right and center channels, 2 surround channels, plus an LFE 0.1 channel as a subwoofer, for a total of 5.1-channels). The unit incorporates a DTS-ES decoder that enables 6.1-channel reproduction by adding the surround back channel to existing 5.1-channel format.

#### ■ Neo:6

Neo:6 decodes the conventional 2-channel sources for 6 channel playback by the specific decoder. It enables playback with the full-range channels with higher separation just like digital discrete signal playback. Two modes are available; "Music mode" for playing music sources and "Cinema mode" for movies.

### Sound field programs

### ■ CINEMA DSP

Since the Dolby Surround and DTS systems were originally designed for use in movie theaters, their effect is best felt in a theater having many speakers and designed for acoustic effects. Since home conditions, such as room size, wall material, number of speakers, and so on, can differ so widely, it's inevitable that there are differences in the sound heard as well. Based on a wealth of actually measured data, YAMAHA CINEMA DSP uses YAMAHA original sound field technology to combine Dolby Pro Logic, Dolby Digital and DTS systems to provide the visual and audio experience of movie theater in the listening room of your own home.

### **■ SILENT CINEMA**

YAMAHA has developed a natural, realistic sound effect DSP algorithm for headphones.

Parameters for headphones have been set for each sound field so that accurate representations of all the sound field programs can be enjoyed on headphones.

### **■ Virtual CINEMA DSP**

YAMAHA has developed a Virtual CINEMA DSP algorithm that allows you to enjoy DSP sound field surround effects even without any surround speakers by using virtual surround speakers.

It is even possible to enjoy Virtual CINEMA DSP using a minimal two-speaker system that does not include a center speaker.

### Audio information

#### ■ ITU-R

ITU-R is the radio communication sector of the ITU (International Telecommunication Union). ITU-R recommends a standard speaker placement which is used in many critical listening rooms, especially for mastering purposes.

### ■ LFE 0.1 channel

This channel is for the reproduction of low bass signals. The frequency range for this channel is 20 Hz to 120 Hz. This channel is counted as 0.1 because it only enforces a low frequency range compared to the full-range reproduced by the other 5/6 channels in Dolby Digital or DTS 5.1/6.1-channel systems.

### ■ PCM (Linear PCM)

Linear PCM is a signal format under which an analog audio signal is digitized, recorded and transmitted without using any compression. This is used as a method of recording CDs and DVD audio. The PCM system uses a technique for sampling the size of the analog signal per very small unit of time. Standing for "pulse code modulation", the analog signal is encoded as pulses and then modulated for recording.

### Sampling frequency and number of quantized bits

When digitizing an analog audio signal, the number of times the signal is sampled per second is called the sampling frequency, while the degree of fineness when converting the sound level into a numeric value is called the number of quantized bits.

The range of rates that can be played back is determined based on the sampling rate, while the dynamic range representing the sound level difference is determined by the number of quantized bits. In principle, the higher the sampling frequency, the wider the range of frequencies that can be played back, and the higher the number of quantized bits, the more finely the sound level can be reproduced.

### Video signal information

### ■ Component video signal

With the component video signal system, the video signal is separated into the Y signal for the luminance and the PB and PR signals for the chrominance. Color can be reproduced more faithfully with this system because each of these signals is independent. The component signal is also called the "color difference signal" because the luminance signal is subtracted from the color signal. A monitor with component input jacks is required in order to use the component signal for output.

### Composite video signal

With the composite video signal system, the video signal is composed of three basic elements of a video picture; color, brightness and synchronization data. A composite video jack on a video component transmits these three elements combined.

### ■ S-video signal

With the S-video signal system, the video signal normally transmitted using a pin cable is separated and transmitted as the Y signal for the luminance and the C signal for the chrominance through the S-video cable. Using the S VIDEO jack eliminates video signal transmission loss and allows recording and playback of even more beautiful images.

# **SPECIFICATIONS**

AUDIO SECTION	VIDEO SECTION
Minimum RMS Output Power for Front, Center, Surround, Surround back	Video Signal Type
$20~\mathrm{Hz}$ to $20~\mathrm{kHz},0.06\%~\mathrm{THD},8~\Omega$ (HTR-5850)	• Signal to Noise Ratio
(HTR-5840) 85 W  • Maximum Power (EIAJ) [China and Korea models]	Frequency Response (MONITOR OUT)     Composite, S-video
1 kHz, 10% THD, 8 Ω (HTR-5850)	FM SECTION • Tuning Range
• Dynamic Power (IHF) 8/6/4/2 Ω (HTR-5850)	[U.S.A. and Canada models]
DIN Standard Output Power [U.K. and Europe models]	• Usable Sensitivity (IHF) 1.0 μV (11.2 dBf)
1 kHz, 0.7% THD, 4 Ω(HTR-5850)	Signal to Noise Ratio (IHF)     Mono/Stereo
• IEC Output Power [U.K. and Europe models] 1 kHz, 0.06% THD, 8 $\Omega$ (HTR-5850)100 W	Harmonic Distortion (1 kHz)     Mono/Stereo
(HTR-5840)95 W	Stereo Separation (1 kHz)
Damping Factor (IHF) 20 Hz to 20 kHz, 8 Ω120 or more	• Frequency Response
Frequency Response     CD terminal to Front L/R 10 Hz to 100 kHz, –3 dB	AM SECTION • Tuning Range
• Total Harmonic Distortion CD, etc. to Front L/R (20 Hz to 20 kHz, 40 W, 8 $\Omega$ ) 0.06% or less	[U.S.A. and Canada models] 530 to 1710 kHz [Other models] 531 to 1611 kHz
Signal to Noise Ratio (IHF-A Network)     CD (250 mV) to Front L/R, Effect Off 100 dB or more	• Usable Sensitivity
• Residual Noise (IHF-A Network) Front L/R	Power Supply     [U.S.A. and Canada models] AC 120 V, 60 Hz
• Channel Separation (1 kHz/10 kHz) CD (5.1 k $\Omega$ terminated) to Front L/R 60 dB/45 dB or more	[Australia model]
Tone Control (Front L/R)     BASS Boost/Cut ±10 dB/60 Hz	[Korea model]
TREBLE Boost/Cut ±10 dB/20 kHz	Power Consumption  Out of the control of the c
• Phones Output	[U.S.A. and Canada models]
Input Sensitivity/Input Impedance     CD, etc	• Standby Power Consumption 0.1 W or less
MULTI CH INPUT	• AC Outlets
• Output Level/Output Impedance REC OUT	[U.K. and Australia models]
SUBWOOFER 4 V/1.2 k $\Omega$	• Dimensions (W x H x D)
	• Weight

### LIST OF REMOTE CONTROL CODES

<del></del>		ELIN	1001	LEYCO	1001	PENNY	0161, 0361, 0521,
TV		ELTA	0331	LG (GOLDSTA	AR) 0031, 0121,		0531, 0621, 0731,
A TANDY	0941	EMERSON	0001, 0021, 0061,		0351, 0411, 0731,		0751, 0761, 0781,
ABEX	1151		0071, 0081, 0091,		0741, 0861, 0941,		0791, 0861, 0931,
ADMIRA	1141		0111, 0811, 0821,		0971, 1001, 1031,		0941, 1031, 1041,
ADVENTURA	A 1131		0831, 0841, 0851,		1111, 1151		1111, 1151, 1161
AIKO	1121		0861, 0871, 0901,	LIESENK & T	TER 1001	PEONY	1561, 1621
AIWA	1481		0921, 0941, 0981,	LLOYTRON	0941	PHILCO	0361, 0581, 0591,
AKAI	0331, 1101, 1111		1011, 1031, 1051,	LOEWE	1001		0601, 0611, 0631,
ALBA	0431		1081, 1091	LOGIK	0991, 1771		0961, 1031, 1111
ALLERON	1091	ENVISION	0361, 1111	LUXMAN	0351, 0971	PHILIPS	0101, 0401, 1001
AMBASSADO	OR 1081	ERRES	1001	LXI	0101, 0621, 0761,	PHONOLA	1001
AMSTRAD	0481, 1081	ETRON	0331		0861, 0981	PILOT	0941, 1031, 1111
ANAM	0251, 1041, 1051,	FERGUSON	1001	MAGNAVOX	0101, 0341, 0391,	PIONEER	0511, 0551, 0871
	1061, 1071	FINLUX	1001		0401, 0411, 0421,	PORTLAND	0941, 1031, 1121
ANAM NATIO		FISHER	0171, 0801, 0981		0581, 0591, 0601,	PRICECLUB	0931
AOC	0361, 1021, 1031,	FORMENTI	0441		0611, 0631, 0661,	PRISM	0751
noc	1111, 1161	FORMONTI	1001		0961, 1111	PROSCAN	0761
ARCHER	1161	FORTRESS	1141	MAJESTIC	0991	PROTECH	1001
AUDIOSONIO		FUJITSU	1091	MARANTZ	0101, 0221, 0361,	PROTON	0501, 0861, 0941,
AUDIOVOX	1051, 1161	FUNAI	1051, 1091, 1501,	MIMATILE	1001, 1111	TROTON	1021, 1161
BAUER	0441	1 011/11	1521	MARK	1001, 1111	PULSAR	0891
BAUR	1001	FUTURETECH		MATSUI	0271, 0331, 1001	PULSER	1031
BEIJING	1511, 1551, 1561	GE	0131, 0161, 0201,	MEDIATOR	1001	QUASAR	0251, 0751, 1041
BELCOR	1031	GE			0691, 0861, 1161	QUELLE	
			0751, 0761, 0771,	MEGATRON	1011	-	1001
BELL & HOW	/ELL 0981, 0991 1001		0781, 0791, 0811, 0861, 1041	MEI ECTRON		RADIO SHAC	2K 0541, 0941, 1031, 1051,
BEON	1051	CEC	· · · · · · · · · · · · · · · · · · ·	M-ELECTRON			
BRADFORD		GEC	0271, 1001	MEMOREX	0331, 0571, 0861,	DADIOLA	1151
BROCKWOO		GEMINI	0391		0971, 0981, 0991,	RADIOLA	1001
BROKSONIC		GENEXXA	0431	METZ	1771	RCA	0051, 0141, 0151,
BUSH	1001	GIBRALTER	0891, 1031, 1111	METZ	1791, 1831, 1891,		0181, 0411, 0491,
CANDLE	0351, 0361, 0961,	GOODMANS/			1901, 1911, 1921,		0531, 0761, 0771,
CADELLADT	0971, 1111, 1131	CDANADA	0271, 0661, 1001	MCA	1931, 1941	DE ALICTIC	0871, 1031
CAPEHART	1021	GRANADA	1001	MGA	0361, 0561, 0571,	REALISTIC	0541, 0861, 0941,
CARVER CATHAY	0101	GRUNDIG	1781, 1791, 1801,	MIDLAND	0861, 1031, 1111		0971, 0981, 1031,
CELEBRITY	1001 0951		1811, 1821, 1831, 1841, 1851, 1861,	MIDLAND	0751, 0761, 0891, 0941, 1151	RHAPSODY	1051, 1111, 1151 1011
CENTURION			1871, 1881	MITCHDICH	0221, 0321, 0561,	R-LINE	1001
	G 1541, 1551, 1561,	GUNPY	1051, 1091	MITSUBISHI	0571, 0661, 0861,	RUNCO	0891, 1111
CHANGION	1621	H/K	0721		1031, 1101, 1381	SAISHO	0331, 1081
CITIZEN	0351, 0361, 0921,	HALLMARK	0861	MONTGOMEI		SAMPO	0361, 0941, 1021,
CITIZEN		HANSEATIC	1001	MOTOROLA		SAMPO	
	0931, 0941, 0961,			MTC		SAMSUNG	1111, 1151
	0971, 1111, 1121,	HARVARD	1051, 1061	MIC	0351, 0361, 0881,	SAMSUNG	0331, 0341, 0351,
CL AIDTONE	1131	HINARI	1001, 1091		0931, 0971, 1011,		0361, 0861, 0931,
CLARIVOY	1011 1001	HITACHI	0181, 0351, 0671,	MULTITECH	1031, 1111		0941, 0971, 1001,
CLARIVOX			0681, 0691, 0701,	MULTITECH	0881, 1051	CAMCITY	1031, 1111, 1151
CONCERTO	0351, 0971		0711, 0871, 0941,	NAD	0551, 0621, 0861	SAMSUX	0941
CONROWA	1751	HWDGON	0971, 1351	NEC	0241, 0351, 0361,	SANYO	0171, 0231, 0271,
CONTEC	0901, 0911, 1011,	HYPSON	1001		0661, 0971, 1031,		0661, 0801, 0911,
CODANDO	1051	IMA	1051	NECKEDMAN	1111, 1321, 1711		0981, 1231, 1251,
CORANDO CRAIG	0941	INDIANA	1001	NECKERMAN		CDD	1261
	0251, 1051	INFINITY REF		NEI	1001	SBR	1001
CROWN	0941, 1051		0101	NIKKAI	0271, 0431, 1001,	SCHEIDER	1001
CURTIS MAT		INTERFUNK		MILLIO	1151	SCIMITSU	1031
	0931, 0941,	ITT	0611	NIKKO	0861, 1111, 1121	SCOTCH	0861
ava	0981, 1111	JANEIL	1131	NOVABEAM	0721	SCOTT	0831, 0861, 0941,
CXC	1051	JBL	0101	NTC	1121		1031, 1051, 1091
DAEWOO	0291, 0301, 0331,	JCB	0951	ONWA	1051	SEARS	0101, 0161, 0171,
	0721, 0941, 1001,	JENSEN	0311	OPTIMUS	0551		0351, 0481, 0521,
	1031, 1121, 1191,	JINXING	1531, 1541, 1551,	OPTONICA	0541, 1141		0621, 0761, 0801,
	1531, 1581, 1591,		1561, 1571, 1621,	ORION	0831, 1001		0861, 0971, 0981,
	1601		1631, 1641, 1651,	OSAKI	0271, 1151		1091
DANSAI	1001	W.C	1691, 1731	OTTO VERSA		SHANGHAI	1561, 1681
DAYTRON	0941, 1031	JVC	0261, 0281, 0641,	PANASONIC	0101, 0191, 0251,	SHARP	0461, 0471, 0541,
DECCA	0271, 1001		0651, 0661, 0841		0751, 1041, 1311,		0661, 0911, 0941,
DIXI	0331, 1001, 1071	KAWASHO	0901		1371, 1431	~~~~	1141
DUMONT	0891, 1031	KAYPANI	1021	PANDA	1541, 1721	SHOGUN	1031
DYNATECH	0881	KENWOOD	0361, 1031, 1111			SIGNATURE	0991, 1771
ELECTROBA		KLOSS	0631, 0721, 1131			SIMPSON	0581, 0961
ELECTROHO	ME 0941	KTV	0921, 0941, 1011,			SOLAVOX	1151
ELECTRON	0941		1051, 1111			SONOKO	1001

SONTEC	1001	BBT 0076	STANDARD COMPONENTS	CRAIG 0832, 0842, 0852,
SONY	0371, 0451, 0661,	CABLETIME 0166	0186	0912, 0922
	0841, 0951, 1281,	CABLEVISION 0196	STARCOM V 0256	CURTIS MATHES 0662, 0822,
	1441	COLOUR VOICE 0306, 0346	STARGATE 0276	0932
SOUNDESIGN	N 0861, 0961, 1051,	COMTRONICS 0216, 0276	SYLVANIA/TEXSCAN	CYBERNEX 0922
	1091	EAGLE COMTRONICS	0376, 0496	DAEWOO 0802, 0812, 0982
SOUNDWAVE		0276	TEKNIKA 0176	DBX 0202
SPECTRICON		EASTERN 0066	TELESERVICE 0056	DYNATECH 0472, 0992
SQUAREVIEV		ELECTRICORD 0206	TELEVIEW 0276	ELECTROHOME 0912
SSS	1031, 1051	ELECTUS 0266	TEXSCAN 0186, 0376	ELECTROPHONIC 0912
STAR-LITE	1051, 1051	GE 0116, 0126	TFC 0026	EMEREX 0792
SUPREM	0951	GEC CABLE SYSTEM	TOCOM 0226, 0356	EMERSON 0072, 0132, 0142,
SUPRE-MAC		0196	TOCOM 5503A 0526	0152, 0162, 0172,
SURPA	0351, 0971	GENERAL INSTRUMENT	TOCOM 5503/10520 TOCOM 5503VIP/5507	0182, 0192, 0212,
SYLVANIA	0101, 0361, 0441,	0926, 0936, 0946	0516	0702, 0712, 0722,
SILVANIA			TOCOM TC56 0506	0702, 0712, 0722, 0732, 0742, 0752,
	0581, 0591, 0601,	HAMLIN H5 0676		
	0611, 0631, 0961,	HAMLIN H6 0666	TOSHIBA 0386	0762, 0772, 0782,
	1111	HAMLIN H6S 0656	TUDI 0046	0872, 0882, 0892,
SYMPHONIC		HAMLIN H8 0646	UNIKA 0136	0912, 0952, 0992,
SYSLINE	1001	HAMLIN H9 0636	UNIVERSAL 0136, 0156, 0206,	1072
TANDY	0271, 0431, 1141	JERROLD 0256	0286	FINLUX 0002, 0992
TATUNG	0271, 0881, 1001,	JERROLD 400L 0626	VIDEOWAY 0096	FISHER 0682, 0692, 0842,
	1041, 1161	JERROLD 450L 0616	VIEWSTAR 0216	0902
TCL	1561, 1631, 1701	JERROLD 550 0606	ZENITH 0246, 0386, 0486	FUJI 0672, 0932
TECHNICS	0751	JERROLD OSD CATV		FUNAI 0992
TECHWOOD	0351, 0751, 0971	0596	<del></del>	GARRARD 0992
TEKNIKA	0101, 0351, 0571,	JERROLD SPRUCER	SATELLITE TUNER	GE 0662, 0822, 0932
	0931, 0941, 0961,	0436	ALPHA STAR 0826	GO VIDEO 0642, 0652
	0971, 0991, 1031,	MAGNAVOX/PHILIPS	CHAPARRAL 0756	GOODMANS 0402
	1051, 1091, 1121,	0416, 0426	ECHOSTAR 0836	GRADIENTE 0992
	1131, 1771	MAMM 0296	GENERAL INSTRUMENT	GRANDA 0612, 0902
TELETECH		MEMOREX 0386		GRUNDIG 0002
	0331		0776, 0876	
TERA	0501	MOTOROLA 0956, 0966	HTS 0836	H/K 1082
THAKRAL	1671	MOVIE TIME 0146, 0206	HUGHES NETWORK SYSTEMS	HARLEY DAVIDSON
THORM	1001	NORTHCOAST 0016	0816	0992
TMK	0351, 0861, 0971,	NSC 0146	JERROLD 0776, 0786	HARMAN/KARDON
	1081	OAK 0106	PANASONIC 0806	0632, 1082
TOSHIBA	0381, 0521, 0621,	OAK SIGMA 450 0546		11 A DAVOOD 0752 0052
TOSHIBA	0501, 0521, 0021,	OAK SIGMA 450 0546	PRIMESTAR 0776, 0786	HARWOOD 0752, 0852
ТОЗНІВА	0661, 0931, 0981,	OAK SIGMA 450 0546 OAK SIGMA 550 0536	RCA 0766	HEADQUARTER 0612
ТОЗНІВА				· · · · · · · · · · · · · · · · · · ·
TOSONIC	0661, 0931, 0981,	OAK SIGMA 550 0536	RCA 0766 SONY 0796	HEADQUARTER 0612
	0661, 0931, 0981, 1301 1011	OAK SIGMA 550 0536 PANASONIC TZ 120/130	RCA 0766 SONY 0796 (DBS)	HEADQUARTER 0612 HI-Q 0842
TOSONIC	0661, 0931, 0981, 1301 1011	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476	RCA 0766 SONY 0796 (DBS) HITACHI 0856	HEADQUARTER 0612 HI-Q 0842 HINARI 0852
TOSONIC TOTEVISION TRICAL	0661, 0931, 0981, 1301 1011 0941 0911	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602,
TOSONIC TOTEVISION TRICAL UNIVERSAL	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942
TOSONIC TOTEVISION TRICAL UNIVERSAL	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306,	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336,	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EEARCH 0361, 1111 1001 0651	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC VIDIKRON	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 SEARCH 0361, 1111 1001 0651 CEPT 1101 0101, 0211	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 SEARCH 0361, 1111 1001 0651 CEPT 1101 0101, 0211 0861, 1031	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EEPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 09911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 09911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986,	RCA 0766 SONY 0796 (DBS)  HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 09911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952,	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONO VIDIKRON VIDTECH VIKING	0661, 0931, 0981, 1301 1011 0941 09911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986,	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0991, 1031, 1091, 1111, 1771	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 1091, 1091, 1011, 1111, 1771 1001	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MAGNIN 0922 MARANTZ 0002, 0202, 0402,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 04446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MAGNIN 0922 MAGNIN 0922 MAGNANTZ 0002, 0202, 0402, 0632, 0932
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 10861, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MARTA 0912 MARTSUSHITA 0932 MATSUI 0722
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EEARCH 0361, 1111 1001 0651 EEPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MARTA 0912 MATSUSHITA 0932 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA	0661, 0931, 0981, 1301 1011 0941 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475 0576	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSU 0722 MEI 0222, 0932 MATSU 0722 MEI 0222, 0932 MEMOREX 02582, 0542, 0472,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA YOKO ZENITH	0661, 0931, 0981, 1301 1011 0941 0941 09911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 04446 PANASONIC TZ140 0466 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75	RCA 0766 SONY 0796 (DBS)  HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNIN 0922 MAGNIN 0922 MARANTZ 0002, 0502, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MAMMOREX 0232, 0242, 0472, 0512, 0612, 0842,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA	0661, 0931, 0981, 1301 1011 0941 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891,	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50 0846 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 0976 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552, 0552, 0632, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LLOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MARANTZ 0002, 0202, 0402, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MEI 0222, 0932 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0922,
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA YOKO ZENITH ZONDA	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50 0846 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 0976 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 75 0366, 0586	RCA 0766 SONY 0796 (DBS)  HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR  A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892 BUSH 0852	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0202, 0402, 0632, 0912 MARTA 0912 MATSUSHITA 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0932, 0992
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA YOKO ZENITH ZONDA	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 8650 0566	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MAGNIN 0922 MARANTZ 0002, 0912 MARANTZ 0002, 0912 MARTA 0912 MATSUSHITA 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0992, 0912, 0922, 0932, 0992 MGA 0762, 0952
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA  YOKO ZENITH ZONDA	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 10861, 0971, 0991, 1031, 1091, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 0976 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 8650 0566 SIGNAL 0276	RCA 0766 SONY 0796 (DBS)  HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR  A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892 BUSH 0852	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0992 MGA 0762, 0952 MGA 0762, 0952 MGA TECHNOLOGY
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA  YOKO ZENITH ZONDA  CABLE TY ABC	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EEARCH 0361, 1111 1001 0651 EEPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 10861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 8650 0566 SIGNAL 0276 SL MARX 0276	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892 BUSH 0852 CALIX 0912	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MAEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0932, 0992 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0932, 0992 MGA 0762, 0952 MGA 0762, 0952 MGA TECHNOLOGY
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA  YOKO ZENITH ZONDA  CABLE TV ABC ANTRONIX	0661, 0931, 0981, 1301 1011 0941 0941 0911 0781, 0791 1001 EARCH 0361, 1111 1001 0651 EPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 0861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR60/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 0976 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 8650 0566 SIGNAL 0276	RCA 0766 SONY 0796 (DBS) HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892 BUSH 0852 CALIX 0912 CANON 0862, 0932	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0992 MGA 0762, 0952 MGA 0762, 0952 MGA TECHNOLOGY
TOSONIC TOTEVISION TRICAL UNIVERSAL UNIVERSUM VECTOR RES  VESTEL VICTOR VIDEO CONC VIDIKRON VIDTECH VIKING WARDS  WATSON XOGEGO YAMAHA  YOKO ZENITH ZONDA  CABLE TY ABC	0661, 0931, 0981, 1301 1011 0941 0911 0781, 0791 1001 EEARCH 0361, 1111 1001 0651 EEPT 1101 0101, 0211 0861, 1031 1131 0101, 0361, 0451, 0541, 0581, 0591, 0601, 0611, 0771, 0781, 0791, 10861, 0971, 0991, 1111, 1771 1001 1611, 1621, 1661, 1741, 1761 0361, 1031, 1111, 1951, 1961, 1971, 1981 1001 0011, 0041, 0891, 0991, 1771 1161	OAK SIGMA 550 0536 PANASONIC TZ 120/130 0476 PANASONIC TZ 170/180 0446 PANASONIC TZ 170/180 0446 PANASONIC TZ140 0466 PANASONIC TZ150/160 0456 PARAGON 0386 PHILIPS 0036, 0216, 0306, 0316, 0326, 0336, 0346 PIONEER 0006, 0086 PIONEER BR50 0846 PIONEER BR50/70/80/81/82 0696 PIONEER BR90 0556 PULSAR 0386 RCA DIGITAL SATELLITE SYSTEM 0396, 0406, 0986, 0996, 1006 REALISTIC 0136 REGENCY/EASTERN0686 RUNCO 0386 SAMSUNG 0276 SCIENTIFIC ATLANTA 175/475 0576 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 75 0366, 0586 SCIENTIFIC ATLANTA 8650 0566 SIGNAL 0276 SL MARX 0276	RCA 0766 SONY 0796 (DBS)  HITACHI 0856 MAGNAVOX 0886 MEMOREX 0886 PANASONIC 0896 PHILIPS 0886 SONY 0906 STAR CHOICE 0876 TOSHIBA 0866, 0916 UNIDEN 0886  VCR  A TANDY 0902 ADVENTURA 0992 AIKO 0982 AIWA 0992 AKAI 0262, 0942, 0952, 0962, 0972 AMERICAN HIGH 0932 AMSTRAD 0992 ASA 0002, 0912 ASHA 0922 AUDIO DYNAMICS 0202 AUDIO DYNAMICS 0202 AUDIOVOX 0912 BEAUMARK 0922 BELL & HOWELL 0902 BLAUPUNKT 0412 BROKSONIC 0872, 0882, 0892 BUSH 0852 CALIX 0912 CANON 0862, 0932 CCE 0852, 0982	HEADQUARTER 0612 HI-Q 0842 HINARI 0852 HITACHI 0102, 0562, 0572, 0582, 0592, 0602, 0992 ITT 0942 JVC (VICTOR) 0202, 0522, 0532, 0542, 0552 KENWOOD 0202, 0542, 0612, 0632, 0902 KLH 0852 KODAK 0912, 0932 LG (GOLDSTAR) 0082, 0632, 0912 LLOYD 0992 LOGIK 0852 LUXOR 0942 LXI 0022, 0912 MAGNAVOX 0002, 0482, 0492, 0502, 0512, 0932 MARANTZ 0002, 0202, 0402, 0632, 0932 MARTA 0912 MATSUSHITA 0932 MATSUI 0722 MEI 0222, 0932 MAEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0932, 0992 MEMOREX 0232, 0242, 0472, 0512, 0612, 0842, 0902, 0912, 0922, 0932, 0992 MGA 0762, 0952 MGA 0762, 0952 MGA TECHNOLOGY

MITSUBISHI	0452, 0462, 0542,	SYLVANIA	0002, 0492, 0502,	MITSUBISHI	0137	OPTIMUS	0225, 0245, 0555,
	0762, 0952, 1082		0762, 0932, 0992	NAD	0137		0595, 0845, 0855,
MOTOROLA		SYMPHONIC		PANASONIC	0077, 0177		0865, 0895, 0935
MTC	0922, 0992	TANDY	0992	PHILIPS	0027	PANASONIC	0055, 0825, 1095,
MULTITECH	0852, 0992	TASHIKO	0712, 0992	PIONEER	0017, 0037, 0137		1125
NAD	0442	TEAC	0992	RCA	0167	PENNY	0905
NEC	0122, 0202, 0292,	TECHNICS	0932	REALISTIC	0157	PHILIPS	0165, 0215
	0422, 0432, 0542,	TEKNIKA	0322, 0912, 0932,	SHARP	0127	PIONEER	0305, 0935, 1045
NWW C	0632		0992	SONY	0047, 0057, 0117	PROTON	0215, 1185
NIKKO	0912	TELEFUNKEN		VICTOR	0097	QUASAR	0055
NOBLEX OLYMPUS	0922 0412, 0932	TMK	0212, 0732, 0772, 0922	YAMAHA	0007, 0067	RCA REALISTIC	0205, 0915, 1115 0205, 0225, 0235,
OPTIMUS	0442, 0472, 0912	TOSHIBA	0062, 0302, 0342,			REALISTIC	0325, 0555, 0845
OPTONICA	0402	1051115/1	0622, 0682, 0712,	CD PLAYE	:R	REVOX	1175
ORION	0212, 0722, 0742,		0762	ACOUSTIC RI	ESEARCH	ROTEL	0215
	0772	TOTEVISION	0912, 0922		1295		OMMANDER (E)
OSAKI	0912	UNITECH	0922	ADC	0025, 0065		0505
PANASONIC	0012, 0052, 0092,	VECTOR RES	EARCH	ADCOM	0205, 0255, 1015	SAE	0215
	0222, 0372, 0382,		0202, 0432, 0632	ADS	0265	SAMSUNG	1285
	0392, 0412, 0932	VIDEO CONC		AIWA	0295, 0945, 1035,	SANSUI	0215, 0625, 0975,
PENNY	0202, 0432, 0602,		0202, 0432, 0632,		1055	G 13770	1025, 1105
	0632, 0692, 0912,	WARR	0952	AKAI	0175, 0485, 0535	SANYO	0145, 0555, 0635,
DENITAV	0922, 0932	WARDS	0322, 0402, 0472, 0482, 0602, 0712,	ALPINE AUDIO-TECH	1215, 1305	SCOTT	0765 0325, 1105
PENTAX PERDIO	0592, 0602 0992		0842, 0852, 0922,	BSR	0245, 0655, 0775	SEARS	0325, 1105
PHILCO	0002, 0932		0932, 0992	CALIFORNIA		SHARP	0235, 0665, 0895,
PHILIPS	0002, 0282, 0402,	YAMAHA	0202, 0632	CALII ORUM	0055	SILIKI	1065, 1075
	0492, 0932	ZENITH	0042, 0362, 0512,	CAPETRONIC		SHERWOOD	0115, 0235, 0395,
PILOT	0912		0672	CARRERA	0245		0475
PIONEER	0442, 0542			CARVER	0285, 1135	SIEMENTS GA	ARRARD
PROSCAN	1002, 1012, 1022,	DVD DL AV	<u></u>	CASIO	0345		1245
	1032, 1042, 1052,	DVD PLAY	EK	CROWN	0185	SIGNATURE	0175
	1062	AKAI	0058	CURTIS MATI		SONTEC	1165
PULSAR	0512	AIWA	0218	DENON	0275, 0875, 0885	SONY	0065, 0565, 0865,
QUARTER	0612	DENON	0188	DEUAL (E)	0505	ami post	1145
QUARTZ	0272, 0612	HITACHI	0198	DYNAMIC BA		STARON	1235
QUASAR RADIO SHAC	0382, 0392, 0932 CK 0912, 0992	JVC KENWOOD	0088, 0178 0148	EMERSON	0555 0205, 0325, 1105	STS SYLVANIA	0025 0215
RADIX	0912, 0992	LG	0228	EROICA	1275	SYMPHONIC	
RANDEX	0912	MAGNAVOX		FISHER	0095, 0555, 0925,	TANDY	0305
RCA	0112, 0382, 0392,	MITSUBISHI		TISTIER	1005	TANGBERG	1195
	0482, 0592, 0602,	ONKYO	0068, 0128	GARRARD	0365	TEAC	0235, 0335, 0385,
	0662, 0822, 0942	PANASONIC	0028	GENEXXA	0305, 0325, 1105		0525, 0795, 0835,
REALISTIC	0402, 0472, 0612,	PHILIPS	0098, 0128	H/K	0105, 0175, 0465,		1355
	0682, 0842, 0902,	PIONEER	0108, 0118		0995	TECHNICS	0055, 0605, 1095
	0912, 0922, 0932,	PROSCAN	0158	HITACHI	0195, 0205, 0505,		1325
	0992	RCA	0158		0815	TELEFUNKEN	
RICOH	0352, 0362	SAMSUNG	0078	INKEL	0115, 0395	THOMSON (E	
SAISHO	0212, 0582, 0722,	SHARP	0038	JVC	0315	TOSHIBA	0035, 0685
SALORA	0732, 0742, 0772 0612, 0762	SONY TECHNICS	0018 0028	KENWOOD	0045, 0095, 0405, 0585, 0725, 0735,	VECTOR RESI	0065, 1135
SAMSUNG	0212, 0312, 0922,	THOMSON	0168		0745, 0755, 0895	VICTOR	0315
Brimserio	0962	TOSHIBA	0048, 0128	KYOCERA	0025	WARDS	0175
SANKY	0472, 0512	YAMAHA	0008, 0028, 0098	LG (GOLDSTA		YAMAHA	0005, 0015, 0085,
SANSUI	0292, 0542, 0832	ZENITH	0128		1265, 1335		0415, 0545, 0575,
SANYO	0242, 0612, 0842,			LUXMAN	0075, 0425, 0675,		1065
	0902, 0922	DVD BECC	ODDED.		0705, 0715, 0985		
SBR	0002, 0282	DVD REC		MAGNAVOX	0165, 0215, 0645,	CD RECOI	DDED
SCHEIDER	0852	PANASONIC			0955		
SCOTT	0342, 0712, 0762,	PHILIPS	0208	MARANTZ	0215, 0235, 0375,	HITACHI	0474
CEADO	0872, 0882, 0892	PIONEER	0278, 0288, 0298	MCDITOGIA	0785, 1345	JVC	0504
SEARS	0302, 0592, 0602,	SHARP	0338, 0348	MCINTOSH MCS	0355, 1085 0905, 1315	MARANTZ	0484, 0494 0444
	0612, 0682, 0692, 0842, 0902, 0912,	SONY TOSHIBA	0308, 0318, 0328 0268	MEMOREX	0205, 0225, 0235,	PHILIPS PIONEER	0454, 0464
	0932	YAMAHA	0208	WEWOKEA	0305, 0325, 1105	YAMAHA	0414
SHARP	0402, 0472	171111111111	0200	MGA	0135	1711/111111	0111
SHINTOM	0852			MISSION	0215		
SHOGUN	0922	LD PLAYE	ĸ	MITSUBISHI	0135, 0445	MD RECO	KUEK
SINGER	0852	AIWA	0157	MTC	1255	KENWOOD	0384
SONY	0032, 0332, 0352,	DENON	0147	NAD	0035, 0615, 0685,	PIONEER	0424
	0362, 0672, 0792,	DISCO VISIO			0695	SHARP	0434
ame	0932	FUNAI	0157	NAKAMICHI	0125, 0435, 0515	SONY	0394
STS	0602	HITACHI (E)	0017	NEC	0255, 0905, 0965	YAMAHA	0024, 0394, 0404,
SUNPAK	0352	KENWOOD	0087, 0107	NIKKO	0545, 1005		0514
		MAGNAVOX MARANTZ	0027 0027	ONKYO	0155, 0455, 0495, 0805, 1155		
		1111 11X1 11 X 1 Z	JU21		0000, 1100		

### **TAPE DECK**

AIWA 0094, 0214, 0224 AKAI 0184 CARVER 0094 DENON 0304 **FISHER** 0144 GARRARD 0194, 0204 JVC 0274, 0284, 0294 KENWOOD 0124, 0134, 0154, 0234, 0244, 0264

MAGNAVOX 0094 MARANTZ 0094, 0344 MITSUBISHI 0184

OPTIMUS 0034, 0064, 0204,

0334

ONKYO 0364, 0374 PHILIPS 0094 PIONEER 0034, 0044, 0064 REVOX 0354 SANSUI 0094, 0344 SHARP 0264 SHERWOOD 0334

SONY 0054, 0084, 0324 TEAC 0194, 0254 TECHNICS 0074, 0314 VICTOR 0294 WARDS 0034

YAMAHA 0004, 0014, 0104,

0114, 0164, 0174, 0264



© 2005 YAMAHA CORPORATION All rights reserved.